



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		87997A 1	THROTTLE CAM (USE WITH BC2)	1		
1		96096	THROTTLE CAM (USE WITH BC2)	1		
2	10	40001 14	SCREW, THROTTLE CAM TO CR.	1		
3	12	87791	WASHER, THROTTLE CAM SCRE	1		
4	13	69150	WAVE WASHER, THROTTLE CAM	1		
5	23	86968	BUSHING, THROTTLE CAM SCRE	1		
6		92425	DASHPOT	1		
7		93001	BRACKET, DASHPOT	1		
8	11	22053	NUT, DASHPOT TERMINAL	2		
9		98463A 1	THROTTLE ROD	1		
10	11	68219	NUT, LOCK - THROTTLE ROD	1		
11		98465	SOCKET, THROTTLE ROD	2		
12		92730	LEVER, CONTROL	1		
13		98464A 1	TIMING ROD	1		
14	11	68219	NUT, LOCK - TIMING ROD	1		
15		98465	SOCKET, TIMING ROD	2		
16		93741	PLATFORM, CONTROL	1		
17	24	89540	SPRING< SPARK ADVANCE	1		
18		93779	LEVER, ACTUATING	1		
19	53	46250	RETAINING RING	1	ACTUATING AND CONTROL LEV	
20		86717	LINK, THROTTLE/ADVANCE	1		
21	53	86731	RETAINING RING, THROTTLE/AI	2		
22		94152	GEAR	1		
23		92362	LEVER, PRIMARY	1		
24	53	46250	RETAINING RING, PRIMARY LEV	1		
25	24	93006	SPRING DETENT BALL	1		
26	30	93008	BALL, DETENT	1		
27		94085	GEAR, SHIFT	1		
28	12	49339	WASHER, SHIFT GEAR	1		
29	53	46250	RETAINING RING, SHIFT GEAR	1		
30		96255 2	SHIFT ROD	1		
31		94084	LEVER, SHIFT ROD	1		
32	10	40015 89	SCREW, SHIFT ROD LEVER	1		
33	23	60762	BUSHING, SHIFT SHAFT	2		
34		87794	SHIFT SHAFT, HORIZONTAL	1		
35		93744	LEVER, SHIFT SHAFT	1		
36		93928	LEVER, ROD END	1		
37	10	40015 88	SCREW, ROD END LEVER	1		
38		94186	BRACKET, THROTTLE CABLE	1		
39	10	40001 71	SCREW, BRACKET TO CYLINDER	3		