



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1390	8888A	CARBURETOR ASSEMBLY (MAN)	1	
1	1390	8676A	CARBURETOR ASSEMBLY (ELEC)	1	
2	1395	9168	THROTTLE VALVE	1	
3	1395	9167	THROTTLE SHAFT	1	
4	1395	9164	FUEL BOWL	1	
5	1395	9169	FLOAT	1	
6	1395	9170	VALVE,INLET NEEDLE	1	
7	1399	5317	JET,MAIN FUEL (.046)	1	
8	1395	9171	PLUG,JET RETAINER	1	
9	1395	9165	COVER,DIAPHRAGM	1	
10	1395	9174	SCREW,DIAPHRAGM COVER	4	
11	1395	9166	COVER,FUEL PUMP	1	
12	1395	9173	SCREW,FUEL PUMP COVER	5	
13	1395	9177	PLATE,COVER(MANUAL)	1	
13	1395	9182	PLATE,COVER(ELECTRIC)	1	
14	1395	9172	SCREW,COVER PLATE	2	
15	1395	9179	GASKET/DIAPHRAGM KIT	1	
16	1395	9178	REPAIR PARTS KIT	1	
17	27	41449	GASKET,CARBURETOR	1	2
18		41717	BRACKET,PRIMER	1	
19	10	40001	8 SCREW,BRACKET TO CARBURE	2	
20		42515A	1 LEVER ASSEMBLY,FAST IDLE	1	
21		41703	1 LEVER,PRIMER	1	
22		42872	1 IDLE WIRE	1	
23		11024	1 ACTUATOR,PRIMER	1	