



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	872	9077A 4	BLOCK/CRANKCASE ASS'	1		
2	17	85171	DOWEL PIN,CYLINDER BLOCK	3		
3	22	71191	ELBOW,BLEED HOSE(45)	2		
4	32	99130 78	HOSE,BLEED(12-1/4")	2		
5	16	42917	STUD,CARBURETOR	2		
6	10	40001209	SCREW,CRANKCASE TO CYLIND	6		
7	27	41475	GASKET,EXHAUST MANIFOLD	1		2
8		92329	EXHAUST MANIFOLD	1		
9	27	41499	GASKET,EXHAUST COVER	1		2
10		92330	COVER,EXHAUST	1		
11	10	40003 33	SCREW,EXHAUST COVER TO CY	10		
12		92349	COVER,TRANSFER PORT	2		
13	25	30503	"O" RING,TRANSFER PORT COV	2		2
14	10	40057107	SCREW,COVER TO CYLINDER BI	4		
15	1028	8283A 1	COVER ASSEMBLY,CYLINDER BI	1		
16	10	40003 31	SCREW,COVER ATTACHING (3	6		
17	27	86389	GASKET,CYLINDER BLOCK COVE	1		2
18	22	99664	ELBOW,TELL TALE HOSE	1		
19	32	34395A 1	HOSE,TELL TALE (8")	1		
20	22	94848	FITTING,TELL TALE HOSE-BOTT	1		
21		92351	COVER,TRANSFER PORT	2		
22	25	86391	"O" RING,TRANSFER PORT COV	2		2
23	10	40057107	SCREW,COVER TO CYLINDER BI	4		
24		92350	COVER,TRANSFER PORT	2		
25	25	33465	"O" RING,TRANSFER PORT COV	2		2
26	10	40057107	SCREW,COVER TO CYLINDER BI	4		
27		42471	REED BLOCK	1		
28		85977	SEAL,REED BLOCK-RUBBER	1		
29	27	41417	GASKET,REED BLOCK	1		2
30	34	99319	REED	2		
31	34	89793	REED STOP	2		
32	10	40057 85	SCREW,REED ATTACHING (10MI	4		
33	27	41418	GASKET,ADAPTOR PLATE	1		2
34		41420A 1	PLATE,ADAPTOR-CARBURETOR	1		
35	22	56759	FITTING,ADAPTOR PLATE-BLE	2		
36	10	40057108	SCREW,PLATE TO REED BLOCK	3		
37	11	40021 3	NUT,CARBURETOR STUD	2		
38		43717	IDLE STOP	1		
39	10	40057108	SCREW,IDLE STOP	2		