



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	88891A 1	HARNES ASSEMBLY,PRIMARY	1		
2		86617A 5	STATOR ASSEMBLY	1		
3	10	40001 20	SCREW,STATOR ATTACHING (2)	2		
4	10	40001 5	SCREW,STATOR ATTACHING (1)	2		
5	54	23568	CLIP,STATOR LEADS	1		
6	10	40057108	SCREW,CLIP TO SWITCH BOX(2)	1		
7		98450A 1	TRIGGER ASSEMBLY	1		
8	54	24836	CLIP,TRIGGER LEADS	1		
9	10	77137	SCRWE,CLIP TO CRANKCASE	1		
10		69205	"C" WASHER,CLIP SCREW	1		
11	339	7370A 8	IGNITION COIL ASSEMBLY	2		
12	10	40001 89	SCREW, COIL TO CYLINDER BLC	2		
13		88173	TAB,COIL SCREW	2		
14	11	45076	NUT,COIL TERMINAL	4		
15	84	99215A25	LEAD ASSEMBLY, HIGH TENSION	2		
16	85	70674	BOOT,COIL	2		
17	85	63709A 1	BOOT ASSEMBLY,SPARK PLUG	2		
18	33	97180	SPARK PLUG,(NGK-BUHW)	2		
19	33	86866	SPARK PLUG,SHAMPION #QL-77	2		
20	339	7452A 3	SWITCH BOX ASSEMBLY	1		
21	10	40057108	SCREW,SWITCH BOX CYLINDER	3		
22	11	45076	NUT,SWITCH BOX TERMINALS	6		
23	23	88171	BUSHING,COIL SCREW	2		
24	13	69432	LOCKWASHER,GROUND	1		