



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1390	8888A 7	CARBURETOR (MANUAL - WMC)	1		
1	1390	8676A 9	CARBURETOR (ELECTRIC - WMC)	1		
2	1395	9640	THROTTLE VALVE	1		
3	1395	9167	THROTTLE SHAFT (WMC - 13/14)	1		
3	1395	9695	THROTTLE SHAFT (WMC-13A/	1		
4	1395	9164	FUEL BOMB	1		
5	1395	9169	FLOAT	1		
6	1395	9170	VALVE, INLET NEEDLE	1		
7	1399	5317	JET, MAIN FUEL (.046)	1		
8	1395	9171	PLUG, JET RETAINER	1		
9	1395	9165	COVER, DIAPHRAGM	1		
10	1395	9174	SCREW, DIAPHRAGM COVER	4		
10	1395	9697	SCREW, DIAPHRAGM COVER	4		
11		15827A 1	BODY, FUEL PUMP	1		
12	1395	9643	SCREW, FUEL PUMP COVER	5		
13	1395	9637	COVER, FUEL PUMP	1		
14	1395	9535	PLUG	1		
15	1395	9645	GASKET/DIAPHRAGM KIT	1		
16	1395	9644	REPAIR PARTS KIT	1		
17	1395	9699	PLATE, COVER (MANUAL)	1		
18	1395	9182	ELECTRIC CHOKE (ELECTRIC -	1		
18	1395	9701	ELECTRIC CHOKE (ELECTRIC -	1		
19	1395	9172	SCREW, COVER PLATE (WMC)	2		
19	1395	9696	SCREW, COVER PLATE (WMC)	2		
20	27	41449	GASKET, CARBURETOR	1		2
21		41717	BRACKET, PRIMER	1		
22	10	40001 8	SCREW, BRACKET TO CARBURE	2		
23		42515A 1	LEVER ASSEMBLY, FAST IDLE	1		
24		41703	LEVER, PRIMER	1		
25		12733	IDLE WIRE	1		
26		11024 2	ACTUATOR, PRIMER	1		
27		12654	INSTRUCTION PLATE (MERCUR)	1		
28		12653	INSTRUCTION PLATE (MARINER)	1		