



| Parts List | | | | | | |
|------------|-------|----------|----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 99589 | GRIP, RUBBER | 1 | | |
| 2 | 84 | 89591A 5 | HARNES ASSEMBLY, STOP SW | 1 | | |
| 3 | | 11099A 1 | BOOT ASSEMBLY, STOP SWIT | 1 | | |
| 4 | | 14170A 1 | HANDLE ASSEMBLY, THROTTLE | 1 | | |
| 5 | 23 | 11193 | RING, STEERING HANDLE | 1 | | |
| 6 | 10 | 62568 | SCREW, THROTTLE HANDLE | 1 | | |
| 7 | | 99333A 2 | TUBE ASSEMBLY, STEERING | 1 | | |
| 8 | | 41590A 1 | TUBE ASSEMBLY | 1 | | |
| 9 | | 94185A 8 | BRACKET ASSEMBLY | 1 | | |
| 10 | 10 | 40056 88 | SCREW, BRACKET CLAMPING | 3 | | |
| 11 | 12 | 57860 | WASHER, NYLON - BRACKET | 1 | | |
| 12 | 11 | 34862 | NUT, BRACKET | 1 | | |
| 13 | 23 | 85973 | BUSHING, BRACKET | 1 | | |
| 14 | | 43242 | CABLE, THROTTLE | 1 | | |
| 15 | 11 | 40021 2 | NUT, THROTTLE CABLE | 4 | | |
| 16 | | 43447A 2 | BRACKET ASSEMBLY, STEERING | 1 | | |
| 17 | 10 | 40003 84 | SCREW, BRACKET TO SWIVEL T | 2 | | |