



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	878	9151	CYLINDER BLOCK AND CRANK	1		
2	17	95218	DOWEL PIN	2		
5	10	95221	SCREW, CRANKCASE TO BLOC	4		
6	10	95298	SCREW, CRANKCASE TO BLOC	2		
7	27	95299	GASKET, CYLINDER HEAD	1		
8	979	9152	CYLINDER HEAD	1		
9	10	95300	SCREW, CYLINDER HEAD	4		
10	12	95222	WASHER, CYLINDER HEAD SCR	4		
11	22	95301	CONNECTOR, DRAIN HOSE	1		
12	32	95223	DRAIN HOSE	1		
13	54	95224	CLIP, DRAIN HOSE	1		
14		95225	HOUSING, CRANKCASE	1		
15	10	95302	SCREW, HOUSING	2		
16	12	95303	WASHER, HOUSING SCREW	2		
17	54	95306	CLAMP, LEAD WIRE	1		
18	34	95226	REED VALVE	1		
19	34	95304	STOP, REED VALVE	1		
20	10	95305	SCREW, REED VALVE	2		
21	53	95236	CLIP, PISTON PIN	2		
22	28	95229	KEY, CRANKSHAFT	1		
23	30	95228	BALL BEARING, CRANKSHAFT (L	1		
24		95230	PLATE, CRANKSHAFT (UPPER)	1		
25	26	95232	OIL SEAL, CRANKSHAFT (UPPER)	1		
26	11	95233	NUT, CRANKSHAFT	1		
27	30	95307	BALL BEARING, CRANKSHAFT (L	1		
28		95231	PLATE, CRANKSHAFT (LOWER)	1		
29	26	95308	OIL SEAL, CRANKSHAFT (LOWE)	1		
30	31	95227	ROLLER BEARING, CONNECTING	1		
31	779	9154	PISTON (STANDARD)	1		
31	779	9183	PISTON (.5MM O.S.)	AR		
32	39	95234	PISTON RING (STANDARD)	1		
32	39	95309	PISTON RING (.5MM O.S.)	AR		
33	41	95235	PISTON PIN	1		
34	474	9153	CRANKSHAFT ASSEMBLY	1		
35	463	813049	CRANKSHAFT	1		
36	463	813268	CRANKSHAFT	1		
37	629	813269	CONNECTING ROD	1		
38	31	813270	BEARING	1		
39		813271	CRANK PIN	1		
-		19251	POWERHEAD	1		