

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	91	31229A 7	BEARING REMOVAL & INSTALLA	1		
-	91	37312	DRIVER HEAD	1		
-	91	37323	DRIVER HEAD ROD	1		
-	91	38628	PULLER HEADD	1		
-			COLLET JAWS (SNAP ON #CG40	1		
-			COLLET JAWS (SNAP ON #CG41	1		
-			EXPANDING ROD (SNAP ON #CE	1		
-			EXPANDING ROD (SNAP ON #CE	1		
-	91	83163M	FLYWHEEL HOLDER	1		
-	91	83164M	FLYWHEEL PULLER	1		
-	12	37429	LOAD WASHER	1		
-	91	24697	PISTON RING EXPANDER	1		
-	91	29287	RING COMPRESSOR	1		
-	91	34569A 1	SLIDE HAMMER	1		
-	91	850439T 1	SPARK GAP TESTER (EIGHT CH/	1		
-	91	63998A 1	SPARK GAP TESTER (SINGLE CF	1		
-	91	66274	TORQUE WRENCH (0-150 LB. IN.	1		
-	91	37241	UNIVERSAL PULLER PLATE	1		

NO IMAGE