



21815

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1390	8889A13	CARBURETOR (WMC-31A) (REPL	1	
1	1390	8677A13	CARBURETOR (WMC-32)	1	
2	1395	9646	THROTTLE VALVE	1	
3	1395	9695	THROTTLE SHAFT	1	
4	1395	9164	FUEL BOWL	1	
5	1395	9169	FLOAT	1	
6	1395	9855	VALVE, INLET NEEDLE	1	
7	1395	6201	JET, (.080), MAIN FUEL	1	
8	1395	9171	PLUG, JET RETAINER	1	
9		813618	COVER, DIAPHRAGM (WMC 31,	1	
9	1395	823648	COVER, Diaphragm, DIAPHRAGI	1	
10	1395	9697	SCREW, DIAPHRAGM COVER	4	
11		15827A 1	BODY, FUEL PUMP	1	
12	1395	9643	SCREW, FUEL PUMP COVER	5	
13	1395	9637	COVER, FUEL PUMP	1	
14	1395	9762	PLUG	1	
15	1395	9803	GASKET/DIAPHRAGM KIT	1	
16	1395	9802	REPAIR PARTS KIT (WMC 31/3	1	
16	1395	823707	REPAIR PARTS KIT (WMC 31A/	1	
17	1395	9699	PLATE, COVER (MANUAL)	1	
18	1395	823433	ELECTRIC CHOKE (ELECTRIC)	1	
19	1395	9696	SCREW, COVER PLATE	2	
20	27	41449 1	GASKET, CARBURETOR	1	2,5
21	1395	9635	DIAPHRAGM/GASKET	1	
22	1395	9633	GASKET	1	
23		F10064	SHAFT	1	
24	1395	824401	FLOAT LEVER	1	
25	10	79964	SCREW, (#6-32 x .750), FAST IDLI	1	
26	24	11277	SPRING, Tension	1	
27	10	40056110	SCREW, (M5 x 30), PRIMER BRAC	2	
27	10	40001 8	SCREW, (M5 x 12), PRIMER BRAC	2	
28	10	79965	SCREW, (#8-32 x .500), PRIMER E	1	
29		11273 1	PRIMER LEVER, PRIMER	1	
30		11280	CAM BLOCK	1	
31	53	11278	CLIP, Retaining	1	
32		17229 1	CHOKE BEZEL	1	
33		12802	KNOB, PRIMER	1	
34		17442	COVER	1	
35	19	47579	PLUG	1	
36		12733 1	IDLE WIRE	1	
37		12805 2	FAST IDLE LEVER	1	