



21815

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1390	8888A 9	CARBURETOR (MANUAL) - WMC	1		
1	1390	8888A10	CARBURETOR (MANUAL) - WMC	1		
1	1390	8676A11	CARBURETOR (ELECTRIC) - WMI	1		
1	1390	8676A12	CARBURETOR (ELECTRIC) - WMI	1		
2	1395	9640	THROTTLE VALVE	1		
3	1395	9695	THROTTLE SHAFT	1		
4	1395	9164	FUEL BOWL	1		
5	1395	9169	FLOAT	1		
6	1395	9855	VALVE, INLET NEEDLE	1		
7	1399	5317	JET, (.046), MAIN FUEL (WMC 2	1		
7	1395	7394	JET, (.044), MAIN FUEL (WMC 3	1		
8	1395	9171	PLUG, JET RETAINER	1		
9		813618	COVER, DIAPHRAGM (WMC 29)	1		
10	1395	9697	SCREW, DIAPHRAGM COVER	4		
11		15827A 1	BODY, FUEL PUMP	1		
12	1395	9643	SCREW, FUEL PUMP COVER	5		
13	1395	9637	COVER, FUEL PUMP	1		
14	1395	9762	PLUG	1		
15	1395	9803	GASKET/DIAPHRAGM KIT	1		
16	1395	9802	REPAIR PARTS KIT (WMC 29/3	1		
16	1395	823649	REPAIR PARTS KIT (WMC 36/3	1		
17	1395	9699	PLATE, COVER (MANUAL)	1		
18	1395	823433	ELECTRIC CHOKE (ELECTRIC)	1		
19	1395	9696	SCREW, COVER PLATE	2		
20	27	41449 1	GASKET, CARBURETOR	1		2,5
21	1395	9635	DIAPHRAGM/GASKET	1		
22	1395	9633	GASKET	1		
23		F10064	SHAFT	1		
24	1395	824401	FLOAT LEVER	1		
25	10	79964	SCREW, (#6-32 x .750), FAST IDL	1		
26	24	11277	SPRING, Tension	1		
27	10	40056110	SCREW, (M5 x 30), PRIMER BRAC	2		
27	10	40001 8	SCREW, (M5 x 12), PRIMER BRAC	2		
28	10	79965	SCREW, (#8-32 x .500), PRIMER E	1		
29		11273 1	PRIMER LEVER	1		
30		11280	CAM BLOCK	1		
31	53	11278	CLIP, Retaining	1		
32		17229 1	CHOKE BEZEL	1		
33		12802	KNOB, PRIMER	1		
34		17442	COVER, CARBURETOR	1		
35	19	42529	PLUG, CARBURETOR COVER	1		