

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		15866 4	SEAL, Adaptor Plate	1		
2		99702A 7	ADAPTOR PLATE ASSEMBLY	1		
3	27	41670006	GASKET, Adaptor Plate	1		2,5
4	10	40011128	SCREW, (M6 x 20)	2		
5		41211	BRACKET	2		
6		NSS	NOT SOLD SEPARATE, Exhaust	1		
7		96248A 1	HOUSING ASSEMBLY	1		
8	23	889715	SPACER, Water Tube	1		
9	26	25329	SEAL	1		2
10	10	40011107	SCREW, (M5 x 16)	2		
11	32	85116	WATER TUBE	1	(Short Shaft)	
11	32	86292	WATER TUBE	1	(Long Shaft)	
12	1588	9097T 5	HOUSING ASSEMBLY	1	(Black-Short Shaft)	
12	1588	9098T 5	HOUSING ASSEMBLY	1	(Black-Long Shaft)	
13	27	43337 4	GASKET, Drive Shaft Housing	1		2
14	127	14621	GASKET	1		2
15		14534	COVER	1		
16	10	14742	SCREW, (.250-20 x 1.25)	1		
17	10	19938 70	SCREW, (M8 x 70)	6		
18	12	40023 17	WASHER	6		
19	10	40011128	SCREW, (M6 x 20)	4		
20		17258T	TRIM COVER	1	(Black)	
-	27	41499A88	GASKET SET	1		
-		804946T02	POWERHEAD	1		

