



5085

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		90906A23	STARTER ASSEMBLY, Recoil	1		
1		86689A 5	HOUSING, Starter	1		
2	10	826253	SCREW, (.250-20 x .625)	1		
3	53	818853	RING, Retaining	1		
4		833161	FELT PAD	1		
5	24	86857 1	SPRING	1		
6	50	825269A 1	SHEAVE, Starter	1		
7	24	86851 2	SPRING	2		
8		86850 1	CAM	2		
9	53	86849 1	RING, Retaining	2		
10		86853 1	CAM	1		
11	24	86852 3	SPRING	1		
12	50	120660 9	ROPE	1		
13		85174A 1	HANDLE ASSEMBLY	1		
14		NSS	NOT SOLD SEPARATE, Retair	1		
15		44180	BUSHING, Rope	1		
16		42626 4	SUPPERT	1		
17	10	40019111	SCREW, (M5 x 35)	2		
18	23	30977 2	SPACER	4		
19		856154	SUPPORT	1		
20	11	40138 5	NUT, (M5)	2		
21		93876 2	LEVER, Lower	1		
22	17	38489	ROLL RIN	1		
23	24	823778	SPRING, Upper Lock Lever	1		
24		858925	LEVER, Lock, Upper	1		
25		42690	BUSHING	1		
26	10	19937 35	SCREW, (M6 x 35)	3	(Non-Seapro/Marathon)	
27	37	827282 2	DECAL, Warning, High Voltage	1		
28		NSS	NOT SOLD SEPARATE, Decal-Sei	1		
29	37	881865	DECAL, Caution-Start in Gear	1	(Start In Gear) (Remote Control)	
30		NSS	NOT SOLD SEPARATE, Decal-Em	1		
31	12	69056	WASHER, (.255 x .620 x .03)	3	(Commercial Engines)	
32	11	40138 6	NUT, (M6)	3	(Commercial Engines)	