

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
0	91	880118A 2	CARTRIDGE	1	SN# 0T979999 & Below	
0	91	880118A04	DDT CARTRIDGE	1	SN# 0T980000 & Up	
0	91	58222A 1	DIAL INDICATOR TOOL, Dial Indic	1		
0	91	822560A 5	ADAPTOR HARNESS	1	(ELECTRICAL/IGNITION)	
0	91	52344	HOLDER TOOL	1		
0	91	827001A 1	POWERHEAD STAND	1		
0	84	825003A 1	DDT CABLE	1	(ELECTRICAL/IGNITION)	
0	91	823686A 2	DIGITAL DIAGNOSTIC TESTER	1	(ELECTRICAL/IGNITION)	
0	91	854009A 3	TACH MULTI METER, DMT 2000	1	(ELECTRICAL/IGNITION) SN# 0T	
0	91	892647A01	MULTI-METER KIT, DMT 2004	1	(ELECTRICAL/IGNITION) SN# 0T	
0	91	24161	CAP TOOL, Flywheel Puller	1		
0	91	52024A 1	SWITCH ASSEMBLY	1	(ELECTRICAL/IGNITION)	
0	91	850439T 1	TESTER	1	(ELECTRICAL/IGNITION)	
0	91	63998A 1	GAP TOOL	1	(ELECTRICAL/IGNITION)	
0	91	99379	TIMING LIGHT	1	(ELECTRICAL/IGNITION)	
0	91	29287	GAUGE TOOL	1	(POWERHEAD)	
0	91	55919	SLEEVE	1	(POWERHEAD)	
0	91	90455T 1	LIFTING EYE	1	(POWERHEAD) SN# 0T979999 &	
0	91	90455 1	LIFTING EYE	1	(POWERHEAD) SN# 0T980000 &	
0	91	93004A 2	LOCK RING INSTALLATION TOOL	1	(POWERHEAD)	
0	91	52952T 1	REMOVAL TOOL, Piston Pin Lock	1	(POWERHEAD)	
0	91	92973A 1	PISTON PIN TOOL	1	(POWERHEAD)	
0	91	24697	EXPANDER TOOL, Ring Expander	1	(POWERHEAD)	
0	91	812549T	SWITCH ASSEMBLY	1	(POWERHEAD)	
0	91	823237T	RING COMPRESSOR	1	(POWERHEAD)	
0	91	66274	TORQUE WRENCH, (0-150 lb-in)	1		
0	91	37241	PULLER PLATE	1		
0	91	11230 1	ALIGNMENT TOOL	1	(TRIM/TILT SYSTEM)	
0	91	74951	SPANNER WRENCH	1	(TRIM/TILT SYSTEM)	
0	91	63209	HEAT LAMP	1	(TRIM/TILT SYSTEM)	
0	91	53459	ROD TOOL	1	(GEAR HOUSING)	
0	91	78473	INDICATOR TOOL, Backlash	1	(GEAR HOUSING)	
0	91	816244	BEARING DRIVER	1	(GEAR HOUSING)	
0	91	816245	BEARING REMOVAL TOOL	1	(GEAR HOUSING)	
0	91	31106T	MANDREL, Bearing Driver Cup	1	(GEAR HOUSING)	
0	91	87120T	BEARING DRIVER CUP	1	(GEAR HOUSING)	
0	91	14311A 2	PRE LOAD TOOL, Bearing	1	(GEAR HOUSING) SN# 0T979999	
0	91	14311A04	TOOL, Preload	1	(GEAR HOUSING) SN# 0T980000	
0	91	31229A 7	PULLER KIT, Bearing	1	(GEAR HOUSING)	
0	91	15755T	MANDREL	1	(GEAR HOUSING)	
0	91	26569T	DRIVEHEAD TOOL	1	(GEAR HOUSING)	

NO IMAGE