

NO IMAGE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	91	822608	5 DDT CARTRIDGE	1		
-	91	822560A	5 ADAPTOR HARNESS	1	(ELECTRICAL/IGNITION)	
-	84	825003A	1 DDT CABLE	1	(ELECTRICAL/IGNITION)	
-	91	823686A	2 DIGITAL DIAGNOSTIC TESTER	1	(ELECTRICAL/IGNITION)	
-	91	99750A	1 MULTI METER	1	(ELECTRICAL/IGNITION)	
-	91	52024A	1 SWITCH ASSEMBLY	1	(ELECTRICAL/IGNITION)	
-	91	59339	1 SERVICE TACHOMETER	1	(ELECTRICAL/IGNITION)	
-	91	850439	1 SPARK TESTER, EIGHT CHAMBE	1	(ELECTRICAL/IGNITION)	
-	91	63998A	1 GAP TOOL, SINGLE CHAMBER	1	(ELECTRICAL/IGNITION)	
-	91	825824A	2 TACH INTERFACE MODULE	1	(ELECTRICAL/IGNITION)	
-	91	99379	1 TIMING LIGHT	1	(ELECTRICAL/IGNITION)	
-	91	11230	1 ALIGNMENT TOOL	1	(TRIM/TILT SYSTEM)	
-	91	99750A	1 MULTI METER	1	(TRIM/TILT SYSTEM)	
-	91	52915A	6 POWER TRIM TEST GAUGE KIT	1	(TRIM/TILT SYSTEM)	
-	91	74951	1 SPANNER WRENCH	1	(TRIM/TILT SYSTEM)	
-	91	44487A	1 TRIM ROD GUIDE REMOVER TO	1	(TRIM/TILT SYSTEM)	
-	91	44486A	1 TRIM ROD REMOVAL TOOL	1	(TRIM/TILT SYSTEM)	
-	91	29287	1 GAUGE TOOL	1	(POWERHEAD)	
-	91	55919	1 SLEEVE	1	(POWERHEAD)	
-	91	52344	1 HOLDER TOOL	1	(POWERHEAD)	
-	91	73687A	2 PULLER KIT	1	(POWERHEAD)	
-	91	90455	1 LIFTING EYE	1	(POWERHEAD)	
-	91	93004A	2 LOCK RING INSTALLATION TOOL	1	(POWERHEAD)	
-	91	52952A	1 LOCKRING REMOVAL TOOL	1	(POWERHEAD)	
-	91	24697	1 TOOL, Ring Expander	1	(POWERHEAD)	
-	91	92973A	1 PISTON PIN TOOL	1	(POWERHEAD)	
-	91	812549	1 POWERHEAD STAND	1	(POWERHEAD)	
-	91	24161	1 CAP TOOL	1	(POWERHEAD)	
-	91	823237	1 RING COMPRESSOR	1	(POWERHEAD)	
-	91	24283	1 SNAP RING PLIERS	1	(POWERHEAD)	
-	91	66274	1 TORQUE WRENCH, (0-150 lb-in)	1	(POWERHEAD)	
-	91	37241	1 PULLER PLATE	1	(POWERHEAD)	
-	91	852087A	1 DUAL FUEL/AIR PRESSURE GAL	1	(DFI)	
-	10	40073	25 SCREW, (M5 x 25)	1	(DFI)	
-	91	851980	1 SEAL/TEFLON RING INSTALLATI	1	(DFI)	
-	91	851980	1 SEAL/TEFLON RING SIZING TOC	1	(DFI)	
-	91	16850A	2 SINGLE FUEL/AIR PRESSURE G	1	(DFI)	
-	91	99750A	1 MULTI METER	1	(DFI)	