



SOLENOID PLATE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		858366T	SOLENOID PLATE	1		
2	89	817109A	SOLENOID	1		
3	25	822179	GROMMET	2		
4	10	821291	SCREW (M6 x 25)	5		
5	23	818968	BUSHING	2		
6		828151A	RELAY ASSEMBLY	3		
7		NSS	DECAL	3		
8		828102	BRACKET	3		
9	23	818968	BUSHING	3		
10	25	818967	GROMMET	3		
11	84	878082T	ENGINE HARNESS	1		
12	88	832969	FUSE	4	(20 AMP)	
12	88	832969	FUSE	1	(15 AMP)	
13		858754	FUSE COVER	1		
14	84	858781A	HARNESS (DIRECT INJECTOR)	1		
15	84	858780A	HARNESS (FUEL INJECTOR)	1		
16	84	858780A	HANRESS (TPS)	1		
-	84	879964A	HARNESS END-Crank Position S	1		
-	84	881262A	HARNESS END-Alternator	1		
17	10	821300	SCREW (M6 x 12)	3		
18	84	819514T	TRIM HARNESS	1		
19	85	850067	INSULATOR BOOT (RED)	1		
20	84	882829A	STARTER CABLE	1	(S/N-0T409000 & UP)	
21	12	29245	WASHER	1		
22	11	813938	CAP NUT	1		
23	11	68292	NUT (5/16-18)	2		
24	11	45076	NUT (10-32)(BRASS)	2		
25	13	53166	LOCKWASHER	2		
26	54	858755	CLIP	1		
27	54	828991	CLIP	1		
28		859610A70	ECM	1	(200 FRESHWATER)	
28		859610A71	ECM	1	(225 FRESHWATER)	
28		859610A72	ECM	1	(200 SALTWATER)	
28		859610A73	ECM	1	(225 SALTWATER)	
29	10	821300	SCREW (M6 x 25)	3		
30	23	856954	BUSHING	3		
31	25	834985	GROMMET	3		
32	12	65567	WASHER	3		
33		859088	CLIP	1		
34	10	821291	SCREW (M6 x 14)	5		
29		881879A	SENSOR WATER PRESSURE	1		