



				Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote	
1		883078A 4	AIR INJECTOR KIT	6			
-	26	804875	SEAL KIT	1			
2	12	828694A 1	WASHER ASSEMBLY, Cupped, Cl	6		5	
-		NSS	NOT SOLD SEPARATE, Fuel Rail,	1			
3		884429T16	FUEL RAIL (PORT)	1			
4		884430T06	FUEL RAIL (STARBOARD)	1			
5	54	804830	CLAMP	4			
6	54	804831	CLAMP	4	SN# 0T979999 & Below		
6	54	804831 1	CLAMP	4	SN# 0T980000 & Up		
7	54	804832	CLAMP	2			
8	54	880816	CLAMP	1			
9	25	804530	O-RING KIT	1			
10	19	804835	PLUG	1			
11	22	804836	FITTING	1			
12		804837	VALVE ASSEMBLY, Air	1			
13		883542	VALVE ASSEMBLY, Fuel	1			
14	19	804839001	CAP	2	SN# 0T979999 & Up		
14	22	805515	CAP, Brass	2	SN# 0T980000 & Up		
15	25	804840	O-RING KIT	1			
16	25	804529	O-RING KIT	1			
17		804533	DIAPHRAGM ASSEMBLY	1			
18	24	804534	SPRING	1			
19	25	804536	O-RING	1			
20		804535	COVER	1			
21		804526	SCREW PACKAGE, (2 Per) (M5	4			
22		804532	O-RING KIT (16 per kit)	1			
23		804525	SCREW PACKAGE, (M5 X 8) (2	15			
24	32	804827	HOSE, Fuel Balance	1			
25	32	889310	HOSE, Fuel Supply, To Vapor Se	1			
26	32	889311	HOSE, Fuel By-Pass	1			
27		804528	INJECTOR, Fuel	6			
28	25	803987	SEAL	1	SN# 0T979999 & Below		
28		804532	O-RING KIT	1	SN# 0T980000 & Up		
29	11	826292	NUT, (M10)	4			
30	54	859376	CLIP, CONDUIT	4	SN# 1B226999 & Below		
30		828791	CLIP	4	SN# 1B227000 & Up		
31	16	858778	STUD, (M10 x 91)	4			
32	54	856880	CLAMP, (15.3)	1			
33	26	888852	SEAL, Fuel Director	1			
-		854198A04	POWERHEAD	1	(200)		
-		877869A04	POWERHEAD	1	(225)		