

NO IMAGE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	91	880118A 2	CARTRIDGE	1	SN# 0T979999 & Below	
-	91	880118A03	DDT CARTRIDGE	1	SN# 0T980000 & Up	
-	91	822560A 5	ADAPTOR HARNESS	1	(ELECTRICAL/IGNITION)	
-	84	825003A 1	DDT CABLE	1	(ELECTRICAL/IGNITION)	
-	91	823686A 2	DIGITAL DIAGNOSTIC TESTER	1	(ELECTRICAL/IGNITION)	
-	91	99750A 1	MULTI METER	1	(ELECTRICAL/IGNITION)	
-	91	52024A 1	SWITCH ASSEMBLY	1	(ELECTRICAL/IGNITION)	
-	91	59339	SERVICE TACHOMETER	1	(ELECTRICAL/IGNITION)	
-	91	850439T 1	TESTER	1	(EIGHT CHAMBER)(ELECTRICAL	
-	91	63998A 1	GAP TOOL	1	(SINGLE CHAMBER)(ELECTRICAL	
-	91	825824A 2	TACH INTERFACE MODULE	1	(ELECTRICAL/IGNITION)	
-	91	99379	TIMING LIGHT	1	(ELECTRICAL/IGNITION)	
-	91	11230 1	ALIGNMENT TOOL	1	(TRIM/TILT SYSTEM)	
-	91	99750A 1	MULTI METER	1	(TRIM/TILT SYSTEM)	
-	91	52915A 6	POWER TRIM TEST GAUGE KIT	1	(TRIM/TILT SYSTEM)	
-	91	74951	SPANNER WRENCH	1	(TRIM/TILT SYSTEM)	
-	91	44487T 1	TRIM ROD GUIDE REMOVER TO	1	(TRIM/TILT SYSTEM)	
-	91	44486A 1	TRIM ROD REMOVAL TOOL	1	(TRIM/TILT SYSTEM)	
-	91	55919	SLEEVE	1	(POWERHEAD)	
-	91	52344	HOLDER TOOL	1	(POWERHEAD)	
-	91	849154T 1	PULLER ASSEMBLY	1	(POWERHEAD)	
-	91	90455T 1	LIFTING EYE	1	(POWERHEAD) SN# 0T979999 &	
-	91	90455 1	LIFTING EYE	1	(POWERHEAD) SN# 0T980000 &	
-	91	93004A 2	LOCK RING INSTALLATION TOOL	1	(POWERHEAD)	
-	91	52952T 1	REMOVAL TOOL	1	(POWERHEAD)	
-	91	24697	EXPANDER TOOL	1	(POWERHEAD)	
-	91	92973A 1	PISTON PIN TOOL	1	(POWERHEAD)	
-	91	812549T	SWITCH ASSEMBLY	1	(POWERHEAD)	
-	91	24161	CAP TOOL	1	(POWERHEAD)	
-	91	823237T	RING COMPRESSOR	1	(POWERHEAD)	
-	91	66274	TORQUE WRENCH, (0-150 lb-in)	1	(0-150 lb in)(POWERHEAD)	
-	91	37241	PULLER PLATE	1	(POWERHEAD)	
-	91	881834A 1	GAUGE	1	(DFI)	
-	10	40073 25	SCREW, (M5 x 25)	1	(DFI)	
-	91	851980 2	SIZING TOOL	1	(DFI)	
-	91	851980 3	INSTALLATION CAP	1	(DFI)	
-	91	881833A 2	FUEL PRESSURE GAUGE	1	(DFI) SN# 0T979999 & Below	
-	91	881833A03	GAUGE KIT, Pressure	1	(DFI) SN# 0T980000 & Up	
-	91	99750A 1	MULTI METER	1	(DFI)	
-	91	53459	ROD TOOL	1	(GEAR HOUSING)	
-	91	78472	BACKLASH INDICATOR TOOL	1	(GEAR HOUSING)	