



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1,1,1		
2	12	36281	WASHER, FLYWHEEL NUT	,1,1	SERIAL 01708179-09999999	
3	25	37340	"O" RING, FLYWHEEL HUB	,1,1	SERIAL 01708179-09999999	
4	28	20094	KEY, FLYWHEEL DRIVE	1,1,1		
5	221	2297A 1	FLYWHEEL ASSEMBLY, COMPLE	1,1,1		
6	10	35563	SCREW, FLEXIBLE PLATE TO F	6,6,6		
7	50	33000A 1	RATCHET ASSEMBLY, FLYWHE	1,1,1		
8	10	32417	SCREW, RATCHET TO FLYW	6,6,6		
9	10	34290	SCREW, RATCHET TO FLYW	2,2,2		
10	13	26992	LOCKWASHER, RATCHET TC	2,2,2		
11	398	2575A 1	STATOR PLATE ASSEMBLY, CON	1,1,1		
12		35599A 1	SHIELD ASSEMBLY, LEAD WIR	1,1,1		
13	13	26996	LOCKWASHER, SHIELD FAST	2,2,2		
14	10	34695	SCREW, LEAD WIRE SHIELD	2,2,2		
15		34601	RING, HOLD DOWN - STATOR	1,1,1		
16	10	35400	SCREW, HOLD DOWN RING TC	4,4,4		
17		34611	CAM, THROTTLE CONTROL - ST,	1,1,1		
18	10	34436	SCREW, THROTTLE CONTROL C	2,2,2		
19		34610	SWIVEL, CONTROL ROD TO THF	1,1,1		
20		34599	ROD, MAGNETO CONTROL	1,1,1		
21		34699	LINK, MAGNETO CONTROL ROD	1,1,1	SERIAL 00000000-01858008	
21		38875	LINK, MAGNETO CONTROL ROD	,,1	SERIAL 01858009-09999999	
22	10	34697	BOLT, SWIVEL - THROTTLE CON	1,1,1		
23	11	20110	NUT, CONTROL ROD LINK TO SV	1,1,1		
24		29013	IDLE STOP, ADJUSTABLE	1,1,1		
25	10	21548	SCREW, IDLE STOP TO TOP COV	1,1,1		
26	12	20028	WASHER, IDLE STOP FASTENIN	1,1,1		
27	11	24652	NUT, IDLE STOP SCREW	1,1,1		
28	15	33910	SHIM, STATOR PLATE TO CRANI	1,1,1		