



Parts List					
Ref	Class	Part	Description	Qty	Comment
1		30269A2	FUEL PUMP ASSEMBLY	1,1,1	
2	27	23005	GASKET, CHECK VALVE TO PU	2,2,2	
3	21	30430	VALVE, CHECK	2,2,2	
4		23004	RETAINER, CHECK VALVE	1,1,1	
5	10	20037	SCREW, RETAINER TO HOUS	2,2,2	
6	27	24863	GASKET, FUEL PUMP	2,2,2	
7		23014	DIAPHRAGM, FUEL PUMP	1,1,1	
8	10	29246	SCREW, FUEL PUMP MOUNTING	2,2,2	
9	10	28712	SCREW, FUEL PUMP MOUNTING	1,1,1	
10	32	28599	FUEL LINE, FUEL PUMP TO CARB	1,1,1	
11	22	23125	FITTING FUEL PUMP OUTLET	1,1,1	
12	22	22995	FITTING, FUEL PUMP INLET TO F	1,1,1	
13	22	22946	SLEEVE, RUBBER	1,1,1	
14	11	22948	NUT, FITTING	1,1,1	
15	32	33475	FUEL LINE, ADAPTOR TO FUEL F	1,1,1	
16		30188	CUP WASHER, ADAPTOR	1,1,1	
17	24	23067	SPRING, ADAPTOR STEM	1,1,1	
18	25	20415	"O" RING, ADAPTOR STEM	1,1,1	
19		23069	STEM, CHECK UNIT ADAPTOR	1,1,1	
20		22833	ADAPTOR, CHECK UNIT	1,1,1	
21	10	27281	SCREW, CHECK UNIT TO STEER	2,2,2	
22	12	20028	WASHER, ADAPTOR FASTENING	4,4	
22	12	20028	WASHER, ADAPTOR FASTENING	2,	
23	12	20583	WASHER, ADAPTOR FASTENING	2,2,2	