



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1627	2090A 3	GEAR HOUSING ASSEMBLY, CO	1,1,1		
1	1627	2090A 1	GEAR HOUSING ASSEMBLY	1,1,1		
2	16	33471	STUD, GEAR HOUSING TO D	1,1,1		
3	16	33472	STUD, WATER PUMP HOUSI	2,2,2		
4	31	28157	BEARING, ROLLER - DRIVE S	1,1,1		
5	17	20201	DOWEL, HOLLOW - DRIVE SF	1,1,1		
6	26	26865	SEAL, RUBBER - WATER INT.	1,1,	SERIAL 00000000-00170817	
6	26	33613	SEAL, RUBBER - WATER INT.	,1,1	SERIAL 01708179-09999999	
7	12	36555	WASHER, NYLON - INTAKE T	,1,1	SERIAL 01708179-09999999	
8	35	33425	SCREEN, WATER INTAKE	1,1,1		
9	10	28642	SCREW, SCREEN TO GEAR F	1,1,1		
10	12	20260	WASHER, GREASE FILLER HOI	1,1,1		
11	10	28634	SCREW, GREASE FILLER HOI	1,1,1		
12	12	20262	WASHER, GREASE VENT HOLE	1,1,1		
13	10	28653	SCREW, GREASE VENT HOLE	1,1,1		
14		33476	SHAFT, SHIFT - LOWER	1,1,1	SERIAL 00000000-01906565	
14		33476A 1	SHAFT ASSY, SHIFT - LOWER	,,1	SERIAL 01906566-09999999	
--	25	38933	"O" RING - SHIFT SHAFT	,,1	SERIAL 01906566-09999999	
15	53	30899	RING, RETAINING - SHIFT SHA	1,1,1		
16	23	30676A 1	BUSHING ASSEMBLY, SHIFT SI	1,1,1		
17	25	26802	"O" RING, SHIFT SHAFT BUS	1,1,1		
18	26	30696	OIL SEAL, SHIFT SHAFT BUSI	1,1,1		
19	10	39149	SCREW, SHIFT SHAFT BUSHIN	1,1,1		
20	43	33441	GEAR, PINION	1,1,1		
21	14	20806	TAB WASHER, PINION GEAR T	1,1,1		
22	10	20807	SCREW, PINION GEAR TO DRP	1,1,1		
23	45	33440	DRIVE SHAFT	1,1,1		
24	15	20804A 1	SHIM, BALL BEARING TO GEAR	AR,AR,		
25	30	20802	BEARING, BALL - DRIVE SHAFT	1,1,1		
26	53	33463	RING, RETAINING - BALL BEAR	1,1,1		
27	15	20804A 1	SHIM, BALL BEARING TO WAT	AR,AR,		
28	46	33408A 1	WATER PUMP HOUSING ASSE	1,1,1		
29	25	33466	"O" RING, WATER PUMP HOI	1,1,1		
30	26	33467	OIL SEAL, WATER PUMP HOI	1,1,1		
31	26	33613	SEAL, WATER INTAKE TUBE	1,1,1		
32	32	33426	TUBE, WATER INTAKE	1,1,1		
33		33429	PLATE, WATER PUMP HOUS	1,1,1		
34		20811	INSERT, WATER PUMP HOU	1,1,1		
35	28	28784	KEY, IMPELLER DRIVE	1,1,1		
36	47	26554	IMPELLER, WATER PUMP	1,1,1		
37		33428	PLATE, FACE, WATER PUMP	1,1,1		