

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1627	2090A 3	GEAR HOUSING ASSEMBLY, CO	1,1,1		
1	1627	2090A 1	GEAR HOUSING ASSEMBLY (SI	1,1,1		
47		33436	CAM, SHIFT	1,1,1		
48		33438	FOLLOWER, CAM	1,1,1		
49	24	33479	SPRING	1,1,1		
50	15	20788A 1	SHIM, BALL BRG. TO GEAR HS	AR,AR,		
--	43	33447A 2	FORWARD BRG ASSY, COMP	1,1,1		
51	30	25398	BEARING, BALL - FORWARD	1,1,1		
52	43	33447A 1	FORWARD GEAR ASSEMBLY	1,1,1		
53	31	28157	BEARING, ROLLER - FORWAR	1,1,1		
54	52	33443	RATCHET, SLIDING CLUTCH	1,1,1		
55	17	33433	PIN, CROSS - RATCHET TO PR	1,1,1		
56	53	33430	RING, RETAINING - CROSS PIN	1,1,1		
57	44	33439	SHAFT, PROPELLER	1,		
57	44	34238A 2	@PROPELLER SHAFT ASSEMBL	1,1,1	SERIAL 01592875-09999999	9
58	43	33444A 1	REVERSE GEAR ASSEMBL	1,1,1		
59	12	33434	WASHER, THRUST - REVER	1,1,1		
60	30	25398	BEARING, BALL - REVERSE	1,1,1		
61	15	33431A 1	SHIM, THRUST WASHER TO G	AR,AR,		
62	25	33465	"O" RING, BEARING CARRIER	1,1,1		
63		33402A 1	BEARING CARRIER ASSEMBLY	1,1,1		
64	31	28157	BEARING, ROLLER - BEARIN	1,1,1		
65	26	27163	OIL SEAL, BEARING CARRIER	1,1,1		
66	26	26805	OIL SEAL, BEARING CARRIER	1,1,1		
67	12	33432	WASHER, GEAR HOUSING COV	1,1,1		
68		33410	COVER, GEAR HOUSING	1,1,1		
69	23	27023	COLLAR, GUIDE - PROPELLER SI	1,		
69	23	34237	COLLAR, GUIDE - PROPELLER SI	1,1,1	SERIAL 01592875-09999999	
70	48	33480A 1	PROPELLER ASSEMBLY (2 BLAD	1,1,1		#
70	48	34402A 1	PROPELLER ASSEMBLY (2 BLAD	OPT,OI		
70		33482A 1	PROPELLER ASSEMBLY (3 BLAD	OPT,OI		
70	48	37316A 1	PROPELLER ASSEMBLY (3 BLAD	OPT,OI		
71	23	27024	SPACER, SPLINE - PROPELLER	1,1,1		
72	12	27025	WASHER, PROPELLER NUT	1,1,1		
73	11	22178	NUT, PROPELLER RETAINING	1,1,1		

