



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	328	1336A 1	FLYWHEEL ASSEMBLY	1		
-	398	1736A 1	STATOR ASSEMBLY, COMPLETE	1		
2	398	1736	STATOR AND CORE	1		
3	398	963	SCREW, CORE FASTENING	4		
4	13	21144	LOCKWASHER, CORE FASTEN	4		
5	398	173	COIL, IGNITION	2		
6	10	21130	SCREW, GROUND TERMINAL	2		
7	398	190	COVER, BREAKER COMPARTM	1		
8	10	30429	SCREW, SEALING COVER FAS	4		
9	398	174	BREAKER ASSEMBLY	2		
10	10	23977	SCREW, BREAKER FASTENING	2		
11	12	21135	WASHER, BREAKER FASTENIN	2		
12	13	21134	LOCKWASHER, BREAKER FAS	2		
13	10	23976	SCREW, BREAKER CONNECTI	2		
14	398	693	CONDENSER	2		
15	10	21136	SCREW, CONDENSER FASTEN	2		
16	13	21134	LOCKWASHER, CONDENSER F	2		
17	398	192	WICK, FELT	1		
--	398	193	PLUG, FELT	1		
18	398	980	LEAD WIRE (SHORT)	1		
19	398	981	LEAD WIRE (LONG)	1		
20		20623	MARKER, "TOP" - LEAD WIRE	1		
21	32	21137	TUBE, LEAD WIRE (PORT SIDE	1		
--	23	25217	BUSHING, LEAD WIRE (STARB	1		
22	398	182	CLAMP, PLASTIC - LEAD WIRE	3		
23	10	23977	SCREW, LEAD WIRE CLAMP (S	1		
24	10	21139	SCREW, LEAD WIRE CLAMP (L	1		
25	12	21135	WASHER, LEAD WIRE CLAMP :	2		
26	13	21134	LOCKWASHER, LEAD WIRE CL	2		
27	398	1098	BUSHING, LEAD WIRES	1		
28		20119	PROTECTOR, SPARK PLUG	2		
29	398	1872	GROUND LEAD, MAGNETO TO	1		
30	23	30419	SLEEVE, GROUND LEAD INSUL	1		
31	25	29051	GROMMET, GROUND LEAD TH	1		
32	33	20127	SPARK PLUG (CHAMPION J6J)	2		
33		33735A 3	THROTTLE CONTROL CAM ASSE	1		
34	10	20616	SCREW, THROTTLE CAM TO ST,	2		
35		29013	IDLE STOP, ADJUSTABLE	1		
36	10	21548	SCREW, IDLE STOP TO TOP CO	1		
37	12	20028	WASHER, IDLE STOP FASTENIN	1		
38	11	24652	NUT, IDLE STOP SCREW	1		