



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1427	1806A 3	CLAMP BRACKET ASSEMBLY	2,2	
2		22477A 4	THUMB SCREW ASSEMBLY	2,2	
3	12	20214	WASHER, THUMB SCREW	2,2	
4		30685	TILT TUBE, CLAMP BRACKET TO	1,1	
5	15	30497A 1	SHIM, CLAMP BRACKET TILT TU	2,2	
6	11	30499	NUT, TILT TUBE FASTENING	2,2	
7	17	28848A 2	TILT LOCK PIN ASSEMBLY	1,1	
8	16	20657	STUD, CLAMP BRACKET	1,1	
9	23	20658	SPACER, CLAMP BRACKET STU	1,1	
10	12	24812	WASHER, CLAMP BRACKET STU	1,1	
11	13	26393	LOCKWASHER, CLAMP BRACKET	2,2	
12	11	20083	NUT, CLAMP BRACKET STUD	2,2	
13	17	39585	SWIVEL PIN	1,1	
14		33423	CO-PILOT DISC	1,1	
15	10	33473	SCREW, CO-PILOT DISC TO SAD	3,3	
16	11	46793	NUT, CO-PILOT DISC TO SADDLE	2,2	
17	1461	2683A 2	SWIVEL BRACKET ASSEMBLY	1,1	
18	25	29845	"O" RING, SWIVEL BRACKET	2,2	4
19	22	31345	FITTING, GREASE - SWIVEL BF	1,1	
20		29359	LUCRICAP, SWIVEL BRACKET Gf	1,1	
21		39307	PLATE, CLAMP - CO-PILOT	1,1	
22		20203	DISC, FRICTION - CLAMP PLATE	4,4	
23	10	29201	SCREW, CLAMP PLATE TO SWIV	1,1	
24	38	39666	SERIAL PLATE	1,1	
25	10	28642	SCREW, DRIVE - SERIAL PLATE	4,4	
26		33512	LEVER, TILT STOP	1,1	
27	10	29237	SCREW, RETAINING - LEVER TO	1,1	
28	13	36076	WASHER, WAVE - TILT STOP LE	1,1	
29	15	37711	SHIM, RETAINING SCREW	1,1	
30	11	46887	NUT, TILT STOP LEVER SCREW	2,2	
31	10	20217	SCREW, ANCHOR - TILT STOP LI	1,1	
32	23	20216	SPACER, TILT STOP LEVER SCR	1,1	
33		33417A 1	REVERSE LOCK LEVER ASSEMB	1,1	
34		26092	ROD, REVERSE LOCK LEVER	1,1	
35	23	26841	BUSHING, NYLON - REVERSE LC	2,2	
36	18	45882	COTTER PIN, REVERSE LOCK LE	1,1	
37	24	33418	SPRING, REVERSE LOCK LEVER	1,1	