



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1123	2705A 2	CRANKCASE TOP ASSEMBLY	1,		
1	1123	3017A 2	CRANKCASE TOP ASSEMBLY	.1		
2	25	31932	"O" RING, CRANKCASE TOP	1,	SERIAL 00000000-02031773	
2	25	20081	"O" RING, CRANKCASE TOP	1,1	SERIAL 02031774-09999999	4
3	15	20514A 1	SHIM, BALL BEARING TO CRANK	AR,AR		
4	30	20464	BEARING, BALL - CRANKCASE	1,1		
5	31	20594	BEARING, ROLLER - CRANKCASE	1,1		
6	26	31684	OIL SEAL, CRANKCASE TOP (U	1,1		
7	10	25299	SCREW, CRANKCASE TOP TY C	2,2		
8	14	20747	TAB WASHER, CRANKCASE TOP	2,2		
9	54	34598	CLIP, HOLD DOWN RING - CRAN	2,2		
10	10	36205	SCREW, RING CLIP TO CRANK	4,4		
11	24	34731	SPRING, TENSION - HOLD DOWN	4,4		
12	830	2669A 3	CYLINDER BLOCK AND CRANKC	1,		
12	830	2753A 3	CYLINDER BLOCK AND CRANKC	.1		
13	22	30139	PLUG, PIPE - CYLINDER BLOCK	1,1		
14	17	23784	PIN, DOWEL - CRANKCASE TO	2,2		
15	16	20462	STUD, CRANKCASE TO CYLINC	.2		
16	11	46793	NUT, CRANKCASE STUD	.2		
17	16	39766	STUD, CYLINDER BLOCK TO D	2,2		
18	16	20991	STUD, CYLINDER BLOCK TO D	2,2		
19	19	20011	WELCH PLUG, CRANKCASE CH	1,1		
20	21	27146A 1	CHECK VALVE ASSEMBLY, CRA	1,1		
21	16	20991	STUD, CRANKCASE TO DRIVE	2,2		
22	16	23740	STUD, CARBURETOR TO CRAN	2,2		
23	10	26066	SCREW, CRANKCASE TO CYLINC	5,5		
24	10	32293	SCREW, CRANKCASE TO CYLINC	1,1		
24	10	21449	SCREW, CRANKCASE TO CYLINC	2,2		
25	10	26123	SCREW, CRANKCASE TO CYLINC	2,2		
26	11	46793	NUT, CRANKCASE SCEW	10,10		
27	25	25429	"O" RING, CRANKCASE SCREW	1,1		4
28	10	26801	SCREW, LOCK - CENTER MAIN B	1,1		
29	14	20091	TAB WASHER, CENTER MAIN BE	1,1		
30	10	22960	SCREW, THROTTLE LIMIT - CRA	2,		
31	11	20013	NUT, JAM - THROTTLE LIMIT SCI	2,		
32		26852	CAP, NYLON - THROTTLE LIMIT :	2,		
33		26174	COVER, TRANSFER PORT	1,1		
34	27	26175	GASKET, TRANSFER PORT COVI	1,1		4
35	10	28635	SCREW, TRANSFER PORT COVE	3,3		
36		39956	CLIP, TRANSFER PORT COVER	2,2		
37	1020	2685	COVER, CYLINDER BLOCK	1,		