



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1561	2672A 2	DRIVE SHAFT HOUSING ASSEMBLY	1	
1	1560	2671A 1	DRIVE SHAFT HOUSING ASSEMBLY	1	
1	1561	2672A 4	DRIVE SHAFT HOUSING ASSEMBLY	1	
1	1560	2671A 2	DRIVE SHAFT HOUSING ASSEMBLY	1	
2	16	33469	STUD, DRIVE SHAFT HSG. TO	1	
2	16	34378	STUD, DRIVE SHAFT HSG. TO	1	
3	16	33470	STUD, DRIVE SHAFT HSG. TO	1,1	
4	19	32298	PLUG, DRIVE SHAFT HOUSING	1	
5	11	21528	NUT, DRIVE SHAFT HOUSING ST	2,2	
6	11	20509	NUT, GEAR HOUSING TO DRIVE	1,1	
7	32	39586	TUBE, WATER OUTLET (SHORT)	1,1	
7	32	39587	TUBE, WATER OUTLET (LONG S	1,1	
8		39301	COVER, TRIM - DRIVE SHAFT HC	1,1	
9	10	35012	SCREW, TRIM COVER TO BOTTC	3,3	
10		39353	SEAL, RUBBER - TRIM COVER	2,2	
11	27	39402	GASKET, MOUNTING PLATE TO	1,1	4
12		39492	PLATE, IDLE RELIEF	1,1	
13	10	35519	SCREW, IDLE RELIEF PLATE TO	2,2	
14	32	45054	TUBE, NYLON - IDLE RELIEF PLA	2,2	
15	25	20195	"O" RING, IDLE RELIEF TUBE	2,2	4
16	11	46793	NUT, POWERHEAD STUDS	6,6	
17		33420	BUMPER, RUBBER - SADDLE	1,1	
18	10	31716	SCREW, RUBBER BUMPER TO S	2,2	
19	13	26992	LOCKWASHER, RUBBER BUMPE	2,2	
20	1562	2673	SADDLE	1,1	
21		33975	MOUNT, RUBBER - UPPER (SHOR	2,2	
21		25150	MOUNT, RUBBER - UPPER (LON	2,2	
22	53	23720	RING, RETAINING - UPPER MOU	2,2	
23		39481	COVER, UPPER MOUNT	2,2	
24	10	39669	SCREW, UPPER MOUNT COVER	2,2	
25		33976	MOUNT, RUBBER - LOWER (SHC	2,2	
25		28281	MOUNT, RUBBER - LOWER (LON	2,2	
26	53	23721	RING, RETAINING - LOWER MDL	2,2	
27	23	31270	SPACER, LOWER MOUNT COVER	2,2	
28		30888	COVER, LOWER MOUNT	2	
28		46418	COVER, LOWER MOUNT	1	
29	10	33726	SCREW, LOWER MOUNT COVER	2,2	
30		33495	LINK ROD, REVERSE LOCK	1,1	
31	24	33413	SPRING, TENSION - REVERSE LI	1,1	
32	11	25980	NUT, REVERSE LOCK LINK ROD	1,1	
32		29241A 1	CAM COUPLING ASSEMBLY, SHU	1,1	