



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1,1		
2	12	36281	WASHER, FLYWHEEL NUT	1,1		
3	25	37340	"O" RING, FLYWHEEL HUB	1,1		4
4	28	20094	KEY, FLYWHEEL DRIVE	1,1		
5	221	2297A 1	FLYWHEEL ASSEMBLY, COMPLE	1,1		
6	10	35563	SCREW, FLEXIBLE PLATE TO F	6,6		
7	50	33000A 1	RATCHET ASSEMBLY, FLYWHE	1,1		
8	10	32417	SCREW, RATCHET TO FLYW	6,6		
9	10	34290	SCREW, RATCHET TO FLYW	2,2		
10	13	26992	LOCKWASHER, RATCHET TC	2,2		
11	398	2575A 1	STATOR PLATE ASSEMBLY, CON	1,1		
12		35599A 1	SHIELD ASSEMBLY, LEAD WIR	1,1		
13	10	45742	SCREW, LEAD WIRE SHIELD	2,2		
14	13	26996	LOCKWASHER, SHIELD SCRE	2,2		
15		34601	RING, HOLD DOWN - STATOR	1,1		
16	10	35400	SCREW, HOLD DOWN RING TC	4,4		
17	15	33910	SHIM, STATOR PLATE TO CRANI	1,1		
18		39296	CAM, THROTTLE CONTROL - ST,	1,		
19	10	34436	SCREW, THROTTLE CONTROL C	2,		
20		34610	SWIVEL, CONTROL LINK TO THF	1,		
21		39596	LINK, THROTTLE CONTROL	1,		
22	13	27071	WASHER, WAVE - THROTTLE CC	1,		
23	12	26013	WASHER, THROTTLE CONTROL	1,		
24	11	20110	NUT, THROTTLE CONTROL LINK	1,		
25		46381	BRACKET, STATOR PLATE	,1		
26	10	34436	SCREW, BRACKET TO STATOR P	,2		
27		46407	LINK ROD, THROTTLE CONTRC	,1		
28	12	30164	WASHER, LINK ROD SWIVEL TO	,1		
29		33973	SWIVEL, LINK ROD TO THROTTI	,1		
30	11	45812	NUT, THROTTLE CONTROL LINK	,2		
31		30212	TERMINAL BLOCK, STATOR PLA	1,1		
32	10	28192	SCREW, TERMINAL BLOCK TO RI	2,2		
33	10	30663	SCREW, GROUND LEADS TO TE	2,2		
34	54	22875	CLIP, STATOR LEADS FASTENIN	1,1		
35	10	30663	SCREW, STATOR LEADS FASTEI	1,1		
36		22789	"D" WASHER, STATOR LEADS F,	1,1		