



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		39654A	FUEL PUMP ASSEMBLY	1,1		
2	21	30430A	CHECK VALVE ASSEMBLY	1,1		
3		23014A	DIAPHRAGM KIT	1,1		4
4			GASKET, CHECK VALVE TO	2,2		4
5			GASKET, FUEL PUMP	2,2		4
6		23004	RETAINER, CHECK VALVE	1,1		
7	10	20037	SCREW, RETAINER TO HOUSII	2,2		
8	10	29246	SCREW, FUEL PUMP TO CYLIND	2,2		
9	10	28712	SCREW, FUEL PUMP TO CYLIND	1,1		
10	22	23125	FITTING, FUEL PUMP OUTLET	1,1		
11	32	28599	FUEL LINE, FUEL PUMP TO CAR	1,1		
12	22	45089	ADAPTOR, FUEL PUMP INLET	1,1		
13	22	22995	FITTING, FUEL PUMP INLET ADA	1,1		
14	22	22946	SLEEVE, RUBBER - FUEL PUMF	1,1		
15	11	22948	NUT, FUEL PUMP INLET FITTIN	1,1		
16	32	33475	FUEL LINE, FUEL PUMP TO ADAF	1,1		
17		30188	CUP WASHER, ADAPTOR	1,1		
18	24	23067	SPRING, ADAPTOR STEM	1,1		
19	25	20415	"O" RING, ADAPTOR STEM	1,1		4
20		23069	STEM, CHECK UNIT ADAPTOR	1,1		
21		22833	ADAPTOR, CHECK UNIT	1,1		
22	10	20784	SCREW, CHECK UNIT ADAPTOR	2,2		
23	11	20361	NUT, CHECK UNIT ADAPTOR SC	2,2		