



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
	398	2575A 1	STATOR PLATE ASSEMBLY, COM	1,1		
1	398	2221	STATOR PLATE AND CORE	1,1		
2	398	2568A 1	COIL ASSEMBLY	2,2		
3	398	2321	CLIP, COIL RETAINING	1,1		
4	398	2413	CLIP, COIL RETAINING	1,1		
5	398	2207	FELT, CAM - BREAKER	1,1		
6	398	732	CLIP, GROUND WIRE LEAD	2,2		
7	10	21130	SCREW, GROUND TERMINAL	2,2		
8	398	2203	CONDENSER ASSEMBLY	2,2		
9	10	38395	SCREW, CONDENSER FASTEN	2,2		
10	13	21134	LOCKWASHER, CONDENSER F	2,2		
11	12	21135	WASHER, CONDENSER FASTE	2,2		
12	54	39844	CLAMP, LEAD WIRE	1,1		
18		22789	"D" WASHER, COIL LEAD WIRE	1,1		
13	12	21135	WASHER, LEAD WIRE CLAMP	1,1		
14	13	21134	LOCKWASHER, LEAD WIRE CL	1,1		
15	11	21923	NUT, LEAD WIRE CLAMP SCRE	1,1		
16	11	21825	NUT, COIL LEAD WIRE CLIP SC	1,1		
17	54	24836	CLIP, NYLON - COIL LEAD WIRE	1,1		
18		22789	"D" WASHER, COIL ELAD WIRE	1,1		
19	13	26395	LOCKWASHER, COIL LEAD WIF	1,1		
20	11	26419	NUT, COIL LEAD WIRE CLIP SC	1,1		
21	398	2320	BREAKER ASSEMBLY	2,2		
22	10	33988	SCREW/LOCKWASHER, BREAK	2,2		
23	12	21135	WASHER, TERMINAL SCREW	2,2		
24	13	21134	LOCKWASHER, TERMINAL SCF	2,2		
25	11	21923	NUT, TERMINAL SCREW	2,2		
26	398	2206	GROUND LEAD, STATOR TO T	1,1		
27	23	30419	SLEEVE, INSULATION - GROUN	1,1		
28	398	2205	LEAD WIRE	1,1		
29	398	2204	LEAD WIRE - TOP	1,1		
30		20119	PROTECTOR, SPARK PLUG	2,2		
31		20623	MARKER, "TOP" - LEAD WIRE	1,1		
32	33	20127	SPARK PLUG, (CHAMPION - J6J)	2,		
32	33	39635	SPARK PLUG, (CHAMPION - L4J)	,2		
33	398	2208	COVER, DUST - STATOR PLATE	1,1		
34	10	36455	SCREW, DUST COVER TO STATI	2,2		