



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
		33405A 4	STEERING HANDLE ASSEMBLY	1,1		
1		27763	GRIP, RUBBER - STEERING HA	1,1		
2		39352	BODY AND SHAFT, STEERING	1,1		
3		31001	INDICATOR, SPEED AND SHIF	1,1		
4	10	31002	SCREW, SET - SPEED AND SHI	1,1		
5	10	22290	SCREW, DRIVE - INDICATOR T	1,1		
6	23	30677	BUSHING, NYLON - STEERING	1,1		
7		33405A 3	STEERING HANDLE ASSEMBL	1,1		
8	23	28100	BUSHING, NYLON - STEERING	1,1		
9	12	30283	WASHER, STEERING HANDLE	2,2		
10	24	26703	SPRING, STEERING HANDLE S	1,1		
11		39211	RETAINER, YOKE PIN HOLDIN	1,1		
12		39208	YOKE, STEERING HANDLE SH	1,1		
13		39210	PLATE, NYLON - THROTTLE CC	2,2		
14	17	26862	PIN, YOKE TO STEERING HAN	1,1		
15		39218	PIVOT, STEERING HANDLE TO B	2,2		
16	15	26707	SHIM, STEERING HANDLE PIVO	2,2		
17	13	39227	WASHER, WAVE - STEERING HA	3,3		
18	13	39228	LOCKWASHER, STEERING HAN	2,2		
19	10	26774	SCREW, STEERING HANDLE TO	2,2		
20		39631A 1	THROTTLE CONTROL SHAFT AS	1,1		
21	10	46923	SCREW, THROTTLE CONTROL S	1,1		
22		39185	SHIELD, STEERING HANDLE	1,1		
23		39302	BRACKET, STEERING ARM	1,1		
24	10	33473	SCREW, STEERING ARM BRACK	3,3		
25	11	46793	NUT, STEERING ARM BRACKET	3,3		