



THROTTLE CONTROL LINKAGE

Parts List					
Ref	Class	Part	Description	Qty	Comment
1	43	39478	GEAR, PINION - THROTTLE CON	1,1	
2	23	31011	BUSHING, NYLON - THROTTLE C	1,1	
3		45160	HOUSING, THROTTLE CONTROL	1,1	
4		45150A 1	SHAFT AND GEAR, THROTTLE S	1,	SERIAL 00000000-02031465
4	43	45440	SHAFT AND GEAR, THROTTLE	1,	SERIAL 02031466-09999999
4	43	46383	SHAFT AND GEAR, THROTTLE	,1	
5	10	20653	SCREW, THROTTLE CONTROL F	1,1	
6	11	46887	NUT, THROTTLE CONTROL HOL	1,1	
7	10	32293	SCREW, THROTTLE CONTROL F	1,1	
8	12	20084	WASHER, THROTTLE CONTROL	1,1	
9	11	46793	NUT, THROTTLE CONTROL HOL	1,1	
10	23	33462	BUSHING, NYLON - SHAFT AND	1,1	
11	12	20413	WASHER, THROTTLE SHAFT AN	AR,AR	
12	13	36206	WASHER, WAVE - THROTTLE SH	1,1	SERIAL 02188145-09999999
13	18	25191	COTTER PIN, THROTTLE SHAFT	1,	
14		39479	LEVER, THROTTLE SHAFT AND	1,	SERIAL 00000000-01973289
14		45152	LEVER, THROTTLE - SHAFT ANC	1,	SERIAL 01973290-09999999
15	10	21625	SCREW, LOCKING - THROTTLE L	1,	SERIAL 00000000-02031465
15	10	45622	SCREW, LOCKING - THROTTLE L	1,	SERIAL 02031466-09999999
16	11	30506	NUT, THROTTLE LEVER LOCKIN	1,	
17	23	30678	BUSHING, NYLON - THROTTLE L	,1	
18		46413	THROTTLE LEVER, VERTICAL SH	,1	
19	10	22960	SCREW, VERTICAL SHAFT THRC	,2	
20	11	25168	NUT, VERTICAL SHAFT THROTT	,2	
21	17	24865	PIN, GROOVE - STATOR PLATE L	,2	
22		46382	LEVER, STATOR PLATE - VERTIC	,1	SERIAL 00000000-02188145
22		46919	LEVER, STATOR PLATE - VERTIC	,1	SERIAL 02188146-09999999
23		46408	LEVER, STATOR PLATE CONTR	,1	
24	10	21807	SCREW, STARTER HOUSING TO	,1	
25	23	46406	BUSHING, STATOR PLATE CONT	,1	
26	11	20361	NUT, STARTER HOUSING TO CF	,1	
27	12	24664	WASHER, SHAFT AND GEAR	,1	
28	11	20586	NUT, SHAFT AND GEAR	,1	
29		46405	LINK, THROTTLE CLUSTER	,1	
30	10	25876	SCREW, THROTTLE CLUSTER L	,1	
31	11	20645	NUT, JAM - THROTTLE CLUSTEF	,1	