



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1561	2672A	DRIVE SHAFT HOUSING ASSEM	1		
1	1560	2671A	DRIVE SHAFT HOUSING ASSEM	1		
2	16	56299	STUD, DRIVE SHAFT HSG. TO	1		
3	16	58134	STUD, DRIVE SHAFT HSG. TO	1		
4	19	32298	PLUG, DRIVE SHAFT HOUSING	1		
5	11	35814	NUT, DRIVE SHAFT HOUSING S	2		
6	11	34863	NUT, GEAR HOUSING TO DRIVE	1		
7	32	39586	TUBE, WATER OUTLET (SHORT)	1		
7	32	39587	TUBE, WATER OUTLET(LONG SH	1		
8		39301	COVER, TRIM - DRIVE SHAFT HC	1		
9	10	35012	SCREW, TRIM COVER TO BOTTC	3		
10		39353	SEAL, RUBBER - TRIM COVER	2		
11	27	39402	GASKET, MOUNTING PLATE TO	1		4
12		39492	PLATE, IDLE RELIEF	1		
13	10	35519	SCREW, IDLE RELIEF PLATE TO	2		
14	32	45054	TUBE, NYLON - IDLE RELIEF PLA	2		
15	25	20195	"O" RING, IDLE RELIEF TUBE	2		4
16	11	46793	NUT, POWERHEADS STUDS	4		
16	11	29250	NUT, POWERHEADS STUDS	2		
17		33420	BUMPER, RUBBER - SADDLE	1		
18	10	31716	SCREW, RUBBER BUMPER TO S	2		
19	13	26392	LOCKWASHER, RUBBER BUMPE	2		
20	1562	2673	SADDLE	1		
21		33975	MOUNT, RUBBER - UPPER(SHOF	2		
21		25150	MOUNT, RUBBER - UPPER(LONG	2		
22	53	23720	RING, RETAINING - UPPER MOU	2		
23		39481	COVER, UPPER MOUNT	2		
24	10	39669	SCREW, UPPER MOUNT COVER	2		
25		33976	MOUNT, RUBBER - LOWER(SHO	2		
25		28281	MOUNT, RUBBER - LOWER(LONI	2		
26	53	23721	RING, RETAINING - LOWER MOL	2		
27		53040	COVER, LOWER MOUNT	2		
28	10	28638	SCREW, LOWER MOUNT COVEF	2		
29		33495	LINK ROD, REVERSE LOCK	1		
30	24	33413	SPRING, TENSION - REVERSE LI	1		
31	11	57146	NUT, REVERSE LOCK LINK ROD	1		
32	10	31716	SCREW, CAM RETAINER TO DRI	1		
33	13	26992	LOCKWASHER, CAM RETAINER	1		
34		39241A	CAM COUPLING ASSEMBLY, SHII	2	SERIAL 02827677-02893435	
35		35653	RETAINER, REVERSE LOCK CA	2	SERIAL 02827677-02893435	
36		23407	LEVER, REVERSE LOCK CAM	1	SERIAL 02827677-02893435	