



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1427	3293A	1 CLAMP BRACKET ASSEMBLY	2		
2		22477A	4 THUMB SCREW ASSEMBLY	2		
3	12	20214	WASHER, THUMB SCREW	2		
4		30685	TILT TUBE, CLAMP BRACKET TO	1		
5	12	52864	SHIM, CLAMP BRACKET TILT TU	2		
6	11	30499	NUT, TILT TUBE FASTENING	2		
7	10	26483	BOLT, CLAMP BRACKET TO TRA	2		
8	12	26485	WASHER, CLAMP BRACKET SCR	2		
9	11	26484	NUT, CLAMP BRACKET SCREW	2		
10	17	56373A	1 TILT LOCK PIN ASSEMBLY	1		
11	16	59620	STUD, CLAMP BRACKET (8")	1		
12	23	59621	SPACER, CLAMP BRACKET STUC	1		
13	13	26393	LOCKWASHER, CLAMP BRACKET	2		
14	11	28770	NUT, CLAMP BRACKET STUD	2		
15	17	39585	SWIVEL PIN	1		
16		33423	CO-PILOT DISC	1		
17	10	26132	SCREW, CO-PILOT DISC TO SAD	3		
18	11	46793	NUT, CO-PILOT DISC TO SADDLE	3		
19	1461	2683A	2 SWIVEL BRACKET ASSEMBLY	1	SERIAL 00000000-03312949	
20	25	29845	"O" RING, SWIVEL BRACKET	2	SERIAL 00000000-03312949	4
21	22	31345	FITTING, GREASE - SWIVEL BF	1	SERIAL 00000000-03312949	
22		29359	LUBRICAP, SWIVEL BRACKET Gf	1	SERIAL 00000000-03312949	
23		39307	PLATE, CLAMP - CO-PILOT	1	SERIAL 00000000-03312949	
24	10	56784	SCREW, CLAMP PLATE TO SWIV	1	SERIAL 00000000-03312949	
19	1461	4752A	2 SWIVEL BRACKET ASSEMBLY	1	SERIAL 03312950-09999999	
20	25	29845	"O" RING, SWIVEL BRACKET	1	SERIAL 03312950-09999999	4
21	22	31345	FITTING, GREASE	1	SERIAL 03312950-09999999	
22		29359	LUBRICAP, SWIVEL BRACKET I	1	SERIAL 03312950-09999999	
23		62054	PLATE, CLAMP - CO-PILOT	1	SERIAL 03312950-09999999	
24	10	62055	SCREW, PLATE TO SWIVEL BF	1	SERIAL 95033129-09999999	
25	12	56720	WASHER, CLAMP PLATE SCRE	1	SERIAL 03312950-09999999	
26		20203	DISC, FRICTION - CLAMP PLATE	4		
27	38	56745	SERIAL PLATE	1		
28	10	25612	SCREW, DRIVE - SERIAL PLATE	4		
29		55851	LEVER, TILT STOP	1		
30	10	29237	SCREW, RETAINING - LEVER TO	1		
31	13	36076	WASHER, WAVE - TILT STOP LE	1		
32	15	37711020	SHIM, RETAINING SCREW	1		
33	11	46887	NUT, TILT STOP LEVER SCREW	2		
34	10	27791	SCREW, ANCHOR - TILT STOP LI	1		
35		61012	LEVER, REVERSE LOCK	1		