



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	415	4478	CRANKSHAFT	1		
2	534	3267A 8	CENTER MAIN BEARING ASSEMI	1		
3	17	20032	DOWEL PIN, CENTER MAIN BE	2		
4	17	55453	PIN, REED STOP	8		
5	10	45775	SCREW, CENTER MAIN BEARII	2		
6	11	45574	NUT, CENTER MAIN BEARING	2		
7	34	56704A 1	REED SET, CENTER MAIN BEAR	1		
8	34	32038	REED STOP, MAIN BEARING REI	4		
9	10	53481	SCREW, REED STOP MOUNTING	4		
10	11	20110	NUT, REED STOP MOUNTING SC	4		
11	17	20032	DOWEL PIN, MAIN BEARING TO	1		
12	28	20094	KEY, FLYWHEEL	1		