



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1627		4404A 4	GEAR HOUSING ASSEMBLY COM	1	A-1627-4404A4 AND 1-1627-4404	
1627		4404A 5	GEAR HOUSING ASSEMBLY COM	1	A-1627-4404A4 AND 1-1627-4404	
1627		4404A 6	GEAR HOUSING ASSEMBLY	1	SEE PAGE Gear Housing Assemb	
1627		4404A 6	GEAR HOUSING ASSEMBLY	1		
50		58975	CAM, SHIFT	1		
51		33438	FOLLOWER, CAM	1		
52	24	33479	SPRING, CAM FOLLOWER	1		
53		47820A 1	PLATE ASSEMBLY, ANADOC - C	1		
54	10	47819	SCREW, ANODIC PLATE TO C	1		
55	15	20788A 1	SHIM, BALL BEARING TO GEAF	AR		
55	30	25398				
56	30	25398	BEARING, BALL - FORWARD GI	1		
57	43	45227	FORWARD GEAR ASSEMBLY	1		
58	31	28157	BEARING, ROLLER - FORWARD	1		
59	52	53518A 1	RATCHET ASSEMBLY, SLIDING	1		
60	17	53372	PIN, CROSS - RATCHET TO P	1		
61	24	53373	SPRING, RETAINING - CROSE	1		
62	44	34238A 2	PROPELLER SHAFT ASSEMBLY	1		
63	43	45229	REVERSE GEAR ASSEMBLY	1		
64	30	25398	BEARING, BALL - REVERSE GE	1		
65	12	33434	WASHER, THRUST - REVERSE	1		
66	15	33431A 1	SHIM, THRUST WASHER TO G	AR		
67	25	33465	"O" RING, BEARING CARRIER	1		
68		33402A 1	BEARING CARRIER ASSEMBLY	1		
69	31	28157	BEARING, ROLLER - BEARIN	1		
70	26	27163	OIL SEAL, BEARING CARRIER	1		
71	26	26805	OIL SEAL, BEARING CARRIER	1		
72	12	33432	WASHER, GEAR HOUSING COV	1		
73		33410	COVER, GEAR HOUSING	1		
74	23	34237	COLLAR, GUIDE - PROPELLER SI	1	PART OF PROPELLER SHAFT A	
75	48	33480A 1	PROPELLER ASSEMBLY (2 BLAD	1	SHIPPED WITH ENGINE FROM I	
75	48	34402A 1	PROPELLER ASSEMBLY (2 BLAD	OPT		
75	48	33482A 1	PROPELLER ASSEMBLY (3 BLAD	OPT		
75	48	37316A 1	PROPELLER ASSEMBLY (3 BLAD	OPT		
76	23	27024	SPACER, SPLINE - PROPELLER	1		
77	11	34933	NUT, PROPELLER RETAINING	1		