



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1		57031A 2	HOUSING ASSEMBLY, STARTER	1			
2	10	37562	SCREW, STARTER HOUSING TO	1			
3	13	26993	LOCKWASHER< STARTER HOUS	1			
4	10	24644	SCREW, STARTER HOUSING TO	1			
4	10	22659	SCREW, STARTER HOUSING TO	1			
5	11	20361	NUT, STARTER HOUSING TO CF	2			
6		47430	BUMPER, RUBBER - STARTER H	1			
7		55860	PULLEY, STARTER CABLE	1			
8	10	37892	SCREW, PULLEY TO STARTER F	1			
9		53111	RETAINER, PULLEY SCREW	1			
10	23	30977	SPACER, PULLEY SCREW	1			
11	11	20110	NUT, PULLEY SCREW	1			
12	14	20165	TAB WASHER, SHEAVE SHAFT M	1			
13	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1			
14		20155	RETAINER, STARTER SPRING	1			
15	24	29340A 1	SPRING, STARTER REWIND	1			
16	23	20159	BUSHING, SPRING GUIDE	1			
17	50	45952	STARTER SHEAVE ASSEMBLY	1			
18	13	29720	WASHER, WAVE - STARTER PA	3			
19		20162	PAUL, STARTER	3			
20	23	45482	SPACER, SHEAVE SHAFT	1			
21		26179	RETAINER, STARTER SHEAVE T	1			
22	12	35559	WASHER, STARTER SHEAVE RE	1			
23	13	20160	WASHER, WAVE - STARTER SHE	1			
24		20164	PLATE< RETAINER - STARTER F	1			
25	24	45823	SPRING, PAUL RETAINER PLATE	1			
26		45481	SHAFT, SHEAVE	1			
27		56305	BRACKET, MOUNTING - TOP CO	1			
28	10	37562	SCREW, REAR MOUNTING BRAC	2			
29		57927	MOUNT, RUBBER - REAR MOUN	1			
30	11	20361	NUT, RUBBER MOUNT TO BRAC	2			
31	397	421A 3	GROUND WIRE ASS'Y, MOUNTIN	1			
32	10	30663	SCREW, GROUND WIRE TO MOU	1			
33		47422	BRACKET< MOUNTING - TOP CO	1			
34	10	37562	SCREW, FRONT MOUNTING BR	2			
35		57927	MOUNT, RUBBER - FRONT MOU	2			
36	11	20361	NUT, RUBBER MOUNT TO BRAC	4			
37	50	22791A 1	STARTER CABLE ASSEMBLY	1			
38		30782	HANDLE, STARTER CABLE	1			
39		28748	RETAINER, STARTER CABLE AN	1			