



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	244	5043A 3	FLYWHEEL ASSEMBLY	1	UNITED STATES 3667342 AND I	
1	244	5043A 7	FLYWHEEL ASSEMBLY	1	UNITED STATES 3667343 THRL	
1	244	5358A 2	FLYWHEEL ASSEMBLY	1	UNITED STATES 3755885 AND I	
2	50	65721	RATCHET ASSEMBLY,FLYWHE	1	UNITED STATES 3667343 THRL	
2	50	33000A 1	RATCHET ASSEMBLY,FLYWHE	1	UNITED STATES 3667342 AND I	
3	10	35563	SCREW,RATCHET TO FLYWF	8	UNITED STATES 3667342 AND I	
4	10	46467	SCREW,RATCHET TO FLYWF	6	UNITED STATES 3667342 AND I	
5	13	26992	LOCKWASHER,RATCHET SCI	2	UNITED STATES 3667342 AND I	
6	28	20094	KEY,FLYWHEEL DRIVE	1		
7	12	36281	WHEEL NUT	1	UNITED STATES 3755884 AND I	
7	12	65891	WASHER,FLYWHEEL NUT	1	UNITED STATES 3755885 AND I	
8	11	22339	NUT,FLYWHEEL	1		
9	338	4992A 1	COIL,HIGH SPEED	1		
9	338	4991A 1	COIL,LOW SPEED	1		
10	54	59538	CLIP,COIL RETAINING	2		
11	54	59539	CLIP,COIL RETAINING	2		
12		64638A 1	STATOR ASSEMBLY	1		
13	10	48637	SCREW,STATOR TO UPPER ENC	3		
14	85	64844	INSULATOR, TERMINAL BLOCK T	1		
15	86	64845	TERMINAL BLOCK,STATOR ASSE	1		
16	10	64843	SCREW,SWITCH BOX LEADS TO	2		
17	11	45076	NUT,SWITCH BOX LEADS TO TE	2		
18	10	48409	SCREW,TERMINAL BLOCK TO S	2		
19	338	4996A 1	TRIGGER ASSEMBLY,IGNITION	1	(Serial No. 4403786 and Below)	
20	17	62768	PIN,IGNITION TRIGGER	1		
21	24	62095	SPRING,COMPRESSION-IGNITIO	1		
22		59783	LINK,THROTTLE-STATOR ASSE	1		
23	12	30164	WASHER,THROTTLE LINK	1		
24		33973	SWIVEL, THROTTLE LINK	1		
25	11	45812	NUT,THROTTLE LINK	2		
26	338	4995A 1	COIL ASSEMBLY,IGNITION	2	UNITED STATES 3755884 AND I	
26	339	5288A 2	COIL ASSEMBLY, IGNITION	2	UNITED STATES 3755885 THRL	
26	339	5748A 2	COIL ASSEMBLY,IGNITION	2	UNITED STATES 4351590 AND I	
27	13	26996	LOCKWASHER, IGNITION COIL T	4		
28	11	45076	NUT,IGNITION COIL TERMINAL	4		
29		66355	COVER,IGNITION COIL	2		
30	10	72073	SCREW,COIL COVER TO REAR S	3		
31	11	20110	NUT,SOIL COVER SCREW	3		
32		54676	RETAINER,HIGH TENSION LEAD	1		
33	84	63212A 2	LEAD ASSEMBLY,HIGH TENSION	2		
34		4760A 1	PROTECTOR ASSEMBLY,SPARK	2		