



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	2130	4361A 2	TOP COWL ASSEMBLY	1			
2		73537	INSERT,ROPE GUIDE-TOP COV	1			
3	53	58656	RING,RETAINING-ROPE GUIDE	1	UNITED STATES 4351589 AND I		
4	16	21553	STUD, TOP COWL TO MOUNTIN	3	UNITED STATES 4351589 AND I		
3	53	72168	RING,RETAINING-ROPE GUIDE	1	UNITED STATES 4351590 AND I		
4	16	72166	STUD, TOP COWL TO MOUNTIN	3	UNITED STATES 4351590 AND I		
5	11	35814	NUT, TOP COWL STUD	1			
6		39400	SHIELD, REAR-TOP COWL	1			
7	10	3737	SCREW, REAR SHIELD TO TOP C	3			
8	2133	2706A 5	WRAP AROUND COWL ASSEMBL	1			
9		39606	BLANKET, WRAP AROUND COV	1			
10		46785A 1	,COWL LATCH ASSEMBLY	2			
11		30413	HOOK, COWL LATCH FASTENIN	2			
12		39628	BUTTON, FRONT COVER RELEAS	1			
13	24	20099	SPRING-COMPRESSION-FRONT	1			
14	12	29245	WASHER, FRONT COVER RELEAS	1			
15		60865	CATCH, FRONT COVER-TOP COW	1			
16	10	37978	SCREW, FRONT COVER LATCH T	2			
17	2127	2666A 8	FRONT COVER ASSEMBLY, COMF	1	UNITED STATES 4102789 AND I		
17	2127	5669A 2	FRONT COVER ASSEMBLY, COMF	1	UNITED STATES 4102790 AND I		
18		60867A 1	BASE ASSEMBLY, FRONT COVE	1			
19	10	48409	SCREW, LATCH BASE TO FRC	2			
20	12	26014	WASHER, LATCH BASE SCREW	AR			
21		60866	HOOK, FRONT COVER LATCH	1			
22	24	39598	SPRING, TORISON-FRONT COV	1			
23	17	39599	PIN, PIVOT-FRONT COVER LATI	1			
24		39936	BLANKET, SOUND ABSORBING	1			