



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	415	5041	CRANKSHAFT	1	UNITED STATES 4403786 AND I	
1	415	6099	CRANKSHAFT	1	UNITED STATES 4403787 AND I	
2		63992A 1	CARRIER ASSEMBLY	1	UNITED STATES 4351589 AND I	
3		64989	SEAL, CARRIER ASSEMBLY	1	UNITED STATES 4351589 AND I	4
2	26	73315	SEAL, CRANKSHAFT	1	UNITED STATES 4351590 AND I	
4	534	3267A18	CENTER MAIN BEARING ASSEMI	1		
5	17	20032	DOWEL PIN, CENTER MAIN BE	2		
6	17	65855	PIN, REED STOP	8		
7	10	45775	SCREW, CENTER MAIN BEARII	2		
8	11	45774	NUT, CENTER MAIN BEARING	2		
9	34	56704A 1	REED SET, CENTER MAIN BEAR	1		
10	34	64632	REED STOP, MAIN BEARING REI	4		
11	10	53481	SCREW, REED STOP MOUNTING	4		
12	11	20110	NUT, REED STOP MOUNTING SC	4		
13	17	20032	DOWEL PIN, MAIN BEARING TO	1		
14	28	20094	KEY, FLYWHEEL	1		