



STARTER ASSEMBLY

| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|-----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 57031A 2 | HOUSING ASSEMBLY, STARTER | 1 | | |
| 2 | 10 | 37562 | SCREW, STARTER HOUSING TO | 1 | | |
| 3 | 13 | 26993 | LOCKWASHER, STARTER HOUSI | 1 | | |
| 4 | 10 | 20653 | SCREW, STARTER HOUSING TO | 1 | UNITED STATES 4351589 AND I | |
| 4 | 10 | 22659 | SCREW, STARTER HOUSING TO | 1 | UNITED STATES 4351589 AND I | |
| 5 | 11 | 46887 | NUT, STARTER HOUSING TO CR. | 2 | UNITED STATES 4351589 AND I | |
| 4 | 10 | 36137 | SCREW, STARTER HOUSING TO | 1 | UNITED STATES 4351590 AND I | |
| 4 | 10 | 72754 | SCREW, STARTER HOUSING TO | 1 | UNITED STATES 4351590 AND I | |
| 5 | 11 | 35888 | NUT, STARTER HOUSING TO CR. | 2 | | |
| 6 | | 47430 | BUMPER, RUBBER-STARTER HO | 1 | | |
| 7 | | 55860 | PULLEY, STARTER CABLE | 1 | | |
| 8 | 10 | 37892 | SCREW, PULLEY TO STARTER H | 1 | | |
| 9 | | 53111 | RETAINER, PULLEY SCREW | 1 | | |
| 10 | 23 | 30977 | SPACER, PULLEY SCREW | 1 | | |
| 11 | 11 | 20110 | NUT, PULLEY SCREW | 1 | | |
| 12 | 14 | 20165 | TAB WASHER, SHEAVE SHAFT N | 1 | UNITED STATES 3755884 AND I | |
| 12 | 14 | 61004 | TAB WASHER, SHEAVE SHAFT N | 1 | UNITED STATES 3755885 AND I | |
| 13 | 11 | 20166 | NUT, SHEAVE SHAFT (LEFT HAN) | 1 | | |
| 14 | | 20155 | RETAINER, STARTER SPRING | 1 | UNITED STATES 3755884 AND I | |
| 14 | | 65890 | RETAINER, STARTER SPRING | 1 | UNITED STATES 3755885 AND I | |
| 15 | 24 | 29340A 1 | SPRING, STARTER REWIND | 1 | | |
| 16 | 50 | 64008A 1 | STARTER SHEAVE ASSEMBLY | 1 | | |
| 17 | 13 | 29720 | WASHER, WAVE-STARTER PAWL | 3 | | |
| 18 | | 20162 | PAWL, STARTER | 3 | | |
| 19 | 23 | 65720 | SPACER, SHEAVE SHAFT (PART C | 1 | | |
| 20 | | 26179 | RETAINER, STARTER SHEAVE TI | 1 | | |
| 21 | 12 | 35559 | WASHER, STARTER SHEAVE RE | 1 | | |
| 22 | 13 | 20160 | WASHER, WAVE-STARTER SHEA | 1 | | |
| 23 | | 20164 | PLATE, RETAINER-STARTER PAW | 1 | | |
| 24 | 24 | 45823 | SPRING, PAWL RETAINER PLATE | 1 | | |
| 25 | | 45481 | SHAFT, SHEAVE | 1 | UNITED STATES 3755884 AND I | |
| 25 | | 65869A 1 | SHAFT ASSEMBLY, SHEAVE | 1 | UNITED STATES 3755885 AND I | |
| 26 | | 64887 | BRACKET, MOUNTING-TOP COW | 1 | UNITED STATES 4403786 AND I | |
| 26 | | 74325 | BRACKET, MOUNTING-TOP COW | 1 | UNITED STATES 4403787 AND I | |
| 27 | 10 | 37562 | SCREW, REAR MOUNTING BRAC | 2 | | |
| 28 | | 57927 | MOUNT, RUBBER-REAR MOUNTI | 1 | | |
| 29 | 11 | 20361 | NUT, RUBBER MOUNT TO BRAC | 2 | | |
| 30 | 84 | 60466A 8 | GROUND WIRE ASSY, REAR BR | 1 | UNITED STATES 4403786 AND I | |
| 30 | 84 | 76180 | GROUND WIRE ASSY REAR BR | 1 | UNITED STATES 4403787 AND I | |
| 30 | 84 | 76181 | GROUND WIRE ASSY REAR BR | 1 | UNITED STATES 4403787 AND I | |
| 31 | 10 | 20653 | SCREW, GROUND WIRE TO C | 1 | | |