



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	43	60856	GEAR, PINION - THROTTLE CON	1		
2		48662	HOUSING, THROTTLE CONTROL	1	UNITED STATES 4580036 AND I	
2		76357	HOUSING, THROTTLE CONTROL	1	UNITED STATES 4580037 AND I	
3	43	60863	SHAFT AND GEAR, THROTTLE	1		
4	10	20653	SCREW, THROTTLE CONTROL F	1	UNITED STATES 4580036 AND I	
5	11	46887	NUT, THROTTLE CONTROL HOL	1	UNITED STATES 4580036 AND I	
6	10	21091	SCREW, THROTTLE CONTROL F	1	UNITED STATES 4580036 AND I	
7	11	46887	NUT, THROTTLE CONTROL HOL	2	UNITED STATES 4580036 AND I	
4&6	10	76213	SCREW, THROTTLE CONTROL F	2	LOWER AND UPPER UNITED S	
8	23	33462	BUSHING, NYLON - SHAFT AND I	1		
9	12	48679	WASHER, THROTTLE SHAFT AN	1		
10	17	36325	PIN, THROTTLE SHAFT AND GE	1		
11		46413	THROTTLE LEVER, VERTICAL SH	1		
12	10	22960	SCREW, VERTICAL SHAFT THRC	2	UNITED STATES 4351589 AND I	
13	11	25168	NUT, VERTICAL SHAFT THROTT	2	UNITED STATES 4351589 AND I	
12	10	72755	SCREW, VERTICAL SHAFT THRC	2	UNITED STATES 4351590 AND I	
13	11	64484	NUT, VERTICAL SHAFT THROTT	2	UNITED STATES 4351590 AND I	
14	17	24865	PIN, GROOVE - STATOR PLATE L	2		
15		60864	LEVER, STATOR PLATE - VERTIC	1		
16		64631	LEVER, STATOR PLATE CONTRC	1		
17	10	22659	SCREW, STARTER HOUSING TO	1		
17	10	72754	SCREW, STARTER HOUSING TO	1		
18	12	57029	WASHER, STARTER HOUSING S	2		
19	23	46406	BUSHING, STATOR PLATE CONT	1		
20	11	20361	NUT, STARTER HOUSING TO CF	1	UNITED STATES 4351589 AND I	
20	11	35888	NUT, STARTER HOUSING TO CF	1	UNITED STATES 4351590 AND I	
21	12	24664	WASHER, SHAFT AND GEAR	1		
22	11	20586	NUT, SHAFT AND GEAR	1		
23		46405	LINK, THROTTLE CLUSTER	1		
24	10	25876	SCREW, THROTTLE CLUSTER L	1		
25	11	20645	NUT, JAM - THROTTLE CLUSTEF	1		