



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		72946	HANDLE, NYLON - SHIFT CONTR	1		
2		66412	BRACKET, MOUNTING - SHIFT SI	1		
3	23	66375	BUSHING, NYLON - SHIFT SHAFI	2		
4		76994	LEVER, SHIFT CONTROL	1		
5		66379	SHAFT, SHIFT (HORIZONTAL)	1		
6	43	66377	GEAR, SECTOR - SHIFT SHAFT	1		
7	12	29245	WASHER, SHIFT CONTROL HAN	1		
8	11	39305	NUT, SHIFT CONTROL HANDLE	1		
9	10	56500	SCREW	2	MOUNTING BRACKET TO POWE	
10	11	46887	NUT, MOUNTING BRACKET SCR	2		
11	24	39627	SPRING, DETENT - MOUNTING E	1		
12		39601	PLATE, DETENT SPRING	1		
13	10	69022	SCREW	2	PLATE AND SPRING TO MOUNT	
14	17	25905	PIN	1	ROLL - SHIFT CONTROL LEVER	
15	12	29245	WASHER, SHIFT SHAFT	1		
16	11	35888	NUT, SECTOR GEAR TO SHIFTS	1		
17		61009A	SHIFT CONTROL SHAFT ASSEME	1		
18	43	58972	GEAR, SECTOR - SHIFT CONTE	1		
19	23	30677	BUSHING, NYLON - SHIFT CONTI	1		
20		58979	FOLLOWER, NEUTRAL SPEED LI	1		
21	10	24644	SCREW	1	FOLLOWER TO POWERHEAD M	
22	15	28212	SHIM, LIMITER FOLLOWER SCRE	1		
23	11	46887	NUT, LIMITER FOLLOWER SCRE	1		
24	24	29675	SPRING, NEUTRAL SPEED LIMIT	1		
25	10	35268	SCREW, SPRING TO LIMITER FO	1		
26		72857	STOP, OVER-SPEED LIMITER	1		
27	12	24676	WASHER, LIMITER STOP SCREW	1		
28	10	46898	SCREW, LIMITER STOP TO FOLL	1		