



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1270	818456A	1 OIL TANK ()	1	S/N-0G437999 & BELOW	
2	1270	830889A	1 OIL TANK ()	1	S/N-0G438000 & UP	
3	23	826084	1 SPACER	1		
4	10	58376	1 SCREW (.164-18 X .375)	1		
5	12	72761	1 WASHER	1		
6	36	814449A	2 CAP ASSEMBLY ()	1	S/N-0G437999 & BELOW	
6	36	814449A	2 CAP ASSEMBLY ()	1	S/N-0G438000 & UP	
7	27	42999	1 GASKET	1		
8	87	12886A	6 SWITCH ASSEMBLY ()	1	S/N-0G437999 & BELOW	
8	87	12886A	7 SWITCH ASSEMBLY ()	1	S/N-0G438000 & UP	
9	23	19064	3 BUSHING	3		
10	25	825380	3 GROMMET	3		
11	12	56720	3 WASHER	3		
12	10	818934	35 SCREW (M8 X 35)	3		
13	32	830756109	1 TUBING (10 IN.) ()	1	S/N-0G437999 & BELOW	
13	32	830756109	1 TUBING (8 IN.) ()	1	S/N-0G438000 & UP	
14	22	42425	4 FITTING	1		
15	10	821045	30 SCREW (30MM)	1		
16		815536	1 OIL PUMP	1		
17	25	11379	1 O-RING	1		
18	25	48462	1 O-RING	1		
19	23	817631	1 BEARING-DRIVEN GEAR	1		
20	43	43020	4 DRIVEN GEAR	1		
21		816974	1 THRUST BEARING	1		
22	10	821045	20 SCREW (20MM)	1		
23	54	816311	1 STA-STRAP	AR		6
24	32	823814	51 TUBING (8-1/2 IN.)	1		4
25	1257	8742	1 OIL TANK	1		
26	36	43298A	2 CAP ASSEMBLY	1		
27	25	11332	1 O-RING	1		
28		816190A	3 ADAPTOR HOUSING ASSEMBLY	1		
29	25	11332	1 O-RING	1		
30	32	99802	1 TUBE	1		
31	32	99439	1 HOSE	1		
32		12335A	1 BRACKET ASSEMBLY	1		
33		12323A	1 BUNGY CORD	1		
34	32	823813	29 TUBING (7 IN.)	1		4