



VAPOR SEPARATOR COMPONENTS

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		883245T 2	COVER KIT	1		
2	22	881740	FITTING, Straight	1		
3	22	883249	FITTING	1		
4		NSS	NOT SOLD SEPARATE, Elbow	2		
5	22	855437A 2	FITTING KIT, Pump Outlet	1	(Use Without Filter)	
5	22	885186A 1	FITTING KIT	1	(Use with Filter)	
6	25	883209	O-RING	1	(Use Without Filter)	
6	25	831985	O-RING, (.468 x .078)	1	(Use with Filter)	
7	35	885188	FILTER	1		
8		883219	VALVE	1		
9	22	15026	C&P	1		
10		883220	C&P	1		
11	19	881830	PLUG	1		
12	26	883248	SEAL	1		
13	27	883252	GASKET	1		
14		883257T 1	REGULATOR	1		
15	25	883593A 1	O-RING KIT	1		
16	12	883258	WASHER	1		
17	10	883261	SCREW, (M5 x .8)	2		
18	10	883261	SCREW, (M5 x .8)	1		
19	84	881831	WIRE ASSEMBLY	1		
20	1395	808612	SCREW AND WASHER, (#8-32 x .7			
21		883253A 1	FLOAT KIT	1		
22		F10064	SHAFT	1		
23		883247A 1	VALVE/SEAT KIT, Inlet	1		
24	10	883223	SCREW, (M6 x 16)	1		
25	35	184580 4	FILTER KIT	1		
26		828586 1	PROBE	1		
27		883260	BAFFLE	1		
28	10	883223	SCREW, (M6 x 16)	3		
29		881705T 1	PUMP KIT	1		
30	23	855428	SLEEVE	1		
31		883256T 1	BOWL KIT	1		
32	26	883248	SEAL	1		
33	19	855435A 1	PLUG KIT	1		
34	25	883209	O-RING	1		
35	10	16955	SCREW, (M6 x 8)	1		