

NO IMAGE

| Parts List | | | | | | |
|------------|-------|-----------|-----------------------------|-----|------------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 0 | 91 | 880118 1 | DDT CARTRIDGE | 1 | | |
| 0 | 84 | 822560A 5 | EFI TEST HARNESS | 1 | (ELECTRICAL/IGNITION) | |
| 0 | 84 | 825003A 1 | HARNESS | 1 | (ELECTRICAL/IGNITION) | |
| 0 | 91 | 823686A 2 | IGNITION DIAGNOSTIC UNIT | 1 | (ELECTRICAL/IGNITION) | |
| 0 | 91 | 99750A 1 | MULTI METER/DVA TESTER | 1 | (ELECTRICAL/IGNITION) | |
| 0 | 91 | 52024A 1 | REMOTE STARTER SWITCH | 1 | (ELECTRICAL/IGNITION) | |
| 0 | 91 | 59339 | SERVICE TACHOMETER | 1 | (ELECTRICAL/IGNITION) | |
| 0 | 91 | 850439T | SPARK GAP TESTER | 1 | (EIGHT CHAMBER)(ELECTRICAL) | |
| 0 | 91 | 63998A 1 | SPARK GAP TESTER | 1 | (SINGLE CHAMBER)(ELECTRICAL) | |
| 0 | 91 | 825824A 2 | TACH INTERFACE MODULE | 1 | (ELECTRICAL/IGNITION) | |
| 0 | 91 | 99379 | TIMING LIGHT | 1 | (ELECTRICAL/IGNITION) | |
| 0 | 91 | 11230 1 | ALIGNMENT TOOL | 1 | (TRIM/TILT SYSTEM) | |
| 0 | 91 | 99750A 1 | MULTI-METER DVA TESTER | 1 | (TRIM/TILT SYSTEM) | |
| 0 | 91 | 52915A 6 | POWER TRIM TEST GAUGE KIT | 1 | (TRIM/TILT SYSTEM) | |
| 0 | 91 | 74951 | SPANNER WRENCH | 1 | (TRIM/TILT SYSTEM) | |
| 0 | 91 | 44487T 1 | TRIM ROD GUIDE REMOVER TO | 1 | (TRIM/TILT SYSTEM) | |
| 0 | 91 | 44486A 1 | TRIM ROD REMOVAL TOOL | 1 | (TRIM/TILT SYSTEM) | |
| 0 | 91 | 29287 | COMPRESSION TESTER | 1 | (POWERHEAD) | |
| 0 | 91 | 55919 | DRIVER HEAD | 1 | (POWERHEAD) | |
| 0 | 91 | 52344 | FLYWHEEL HOLDER | 1 | (POWERHEAD) | |
| 0 | 91 | 849154T 1 | FLYWHEEL PULLER | 1 | (POWERHEAD) | |
| 0 | 91 | 90455T | LIFTING EYE | 1 | (POWERHEAD) | |
| 0 | 91 | 93004A 2 | LOCK RING INSTALLATION TOOL | 1 | (POWERHEAD) | |
| 0 | 91 | 52952T 1 | LOCK RING REMOVAL TOOL | 1 | (POWERHEAD) | |
| 0 | 91 | 24697 | PISTON RING EXPANDER | 1 | (POWERHEAD) | |
| 0 | 91 | 92973A 1 | PISTON PIN TOOL | 1 | (POWERHEAD) | |
| 0 | 91 | 812549T | POWERHEAD STAND | 1 | (POWERHEAD) | |
| 0 | 91 | 24161 | PROTECTOR CAP-FLYWHEEL | 1 | (POWERHEAD) | |
| 0 | 91 | 823237T | RING COMPRESSOR | 1 | (POWERHEAD) | |
| 0 | 91 | 66274 | TORQUE WRENCH | 1 | (0-150 lb in)(POWERHEAD) | |
| 0 | 91 | 37241 | UNIVERSAL PULLER PLATE | 1 | (POWERHEAD) | |
| 0 | 91 | 852087A 3 | DUAL FUEL/AIR PRESSURE GAL | 1 | (DFI) | |
| 0 | 10 | 40073 25 | SCREW (M5 x 25) | 1 | (DFI) | |
| 0 | 91 | 851980 2 | SEAL/TEFLON RING INSTALLATI | 1 | (DFI) | |
| 0 | 91 | 851980 3 | SEAL/TEFLON RING SIZING TOC | 1 | (DFI) | |
| 0 | 91 | 881833A 2 | SINGLE FUEL/AIR PRESSURE G | 1 | (DFI) | |
| 0 | 91 | 99750A 1 | VOLT/OHM METER | 1 | (DFI) | |
| 0 | 91 | 53459 | BACKLASH INDICATOR ROD | 1 | (GEAR HOUSING) | |
| 0 | 91 | 78473 | BACKLASH INDICATOR TOOL | 1 | (GEAR HOUSING) | |
| 0 | 91 | 816244 | BEARING DRIVER | 1 | (GEAR HOUSING) | |
| 0 | 91 | 31105T | BEARING DRIVER CUR | 1 | (GEAR HOUSING) | |