



1322

				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		858366T 2	SOLENOID PLATE	1		
2	54	858755	CLIP	1		
3	89	817109A 2	SOLENOID	1		
4	25	822179	GROMMET	2		
5	10	821291 25	SCREW (M6 x 25)	5		
6	23	818968	BUSHING	2		
7		882751A 1	RELAY ASSEMBLY	3		
8		828102	BRACKET	3		
9	23	818968	BUSHING	3		
10	25	818967	GROMMET	3		
11	54	828991	CLIP	1		
12	12	29245	WASHER	1		
13	11	45076	NUT (10-32)(BRASS)	2		
14	11	813938	CAP NUT	1		
15	84	878231A 6	FUSE HARNESS	1		
16	84	882829A 1	STARTER CABLE	1		
17	13	53166	LOCKWASHER	2		
18	11	68292	NUT (5/16-18)	2		
19	85	850067 1	INSULATOR BOOT (RED)	1		
20	84	819514T18	TRIM HARNESS	1		
21		85961091S	PCM	1	(200)	1
21		85961092S	PCM	1	(225)	1
22	10	821300 25	SCREW (M6 x 25)	3		
23	12	65567	WASHER	3		
24	25	834985	GROMMET	3		
25	23	856954	BUSHING	3		
26		859088 1	CLIP	1		
27	10	821291 14	SCREW (M6 x 14)	5		
28	84	878082T 8	ENGINE HARNESS	1		1
29	88	832969 20	FUSE	4	(20 AMP)	
29	88	832969 5	FUSE	1	(5 AMP)	
30		858754	FUSE COVER	1		
-	84	858781A 2	HARNESS END (DIRECT INJEC	1		
-	84	858780A 2	HARNESS END (FUEL INJECTO	1		
-	84	881262A 2	HARNESS END-Alternator	1		
-	84	878073A 2	HANRESS END (TPS)	1		
31	54	816311T	STA-STRAP	AR		
32	10	821300 12	SCREW (M6 x 12)	3		
33	10	818934 20	SCREW (M8 x 20)	1		
34	84	88439A26	BATTERY CABLE (NEGATIVE)	1		
35		822848A 1	CONNECTOR	1	(TRACKER)	