



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		NSS	FUEL RAIL ASSEMBLY	1		
1		850065A11	INJECTOR	6		
1		883078A 1	INJECTOR	6	(SALTWATER)	
2	12	828694A 1	CUPPED WASHER	6		5
3		884429A 8	FUEL RAIL (PORT)	1	(REFERENCE SERVICE BULLET	
4		858259A 1	FUEL RAIL (STARBOARD)	1	(W/O FUEL INJECTORS)	
5	54	804830	CLAMP	4		
6	54	804831	CLAMP	4		
7	54	804832	CLAMP	2		
8	54	880816	CLAMP	1		
9	25	804529	O RING KIT	1		
10	19	804835	AIR PLUG	1		
11	22	804836	FITTING	1		
12		804837	AIR VALVE KIT	1		
13		804838A 1	FUEL VALVE KIT	1		
14	19	804839	CAP	2		
15	25	804840	O RING KIT	1		
16	25	804530	O RING KIT	1		
17		804533	DIAPHRAGM	1		
18	24	804534	SPRING	1		
19	25	804536	O RING	1		
20		804535	COVER	1		
21		804526	SCREW (M5 X 16)	4		
22		804532	O RING	1	(16 PER KIT)	
23		804525	SCREW (M5 X 8)	15		
24		880807T	AIR REGULATOR	1		
25	54	880808	CLAMP	1		
26	25	880809	O RING KIT	1		
27		804528	FUEL INJECTOR	6		
28	16	858778	STUD (M10 X 91)	4		
29	11	826292	NUT (M10)	4		
30	54	859376	CLIP-CONDUIT	4		
31	26	804875	SEAL KIT	1		
-		<a href="#">877869A01</a>	POWERHEAD	1	(225)	
-		<a href="#">854198A01</a>	POWERHEAD	1	(200)	