



1408

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		887857T	EXHAUST COVER, Inner (Starboard)	1	(Use without Anodes)	6
1		887857T01	EXHAUST COVER, Inner (Starboard)	1	(Use with Anodes)	6
2	27	887861	GASKET	2	(Use without Anodes)	2,6,24
2	27	887861001	GASKET	2	(Use with Anodes)	2,6,24
3	27	887862	GASKET	2	(Use without Anodes)	2,6,24
3	27	887862001	GASKET	2	(Use with Anodes)	2,6,24
4		887859T	EXHAUST COVER, Outer (Starboard)	1	(Use without Anodes)	6
4		887859T01	EXHAUST COVER, Outer (Starboard)	1	(Use with Anodes)	6
5	10	887863	BOLT	28		6,24
6	10	831247 14	BOLT	4		6,24
7	12	831246	WASHER, Sealing	4		2,6,24
8	10	881425	SCREW PLUG	2		6,24
9	27	881426	GASKET	2		2,6,24
10		887858T	EXHAUST COVER, Inner (Port)	1	(Use without Anodes)	24
10		887858T01	EXHAUST COVER, Inner (Port)	1	(Use with Anodes)	24
11		887860T	EXHAUST COVER, Outer (Port)	1	(Use without Anodes)	24
11		887860T01	EXHAUST COVER, Outer (Port)	1	(Use with Anodes)	24
12		887864	LIFTING EYE	2		
13	10	881428	BOLT, (M6 x 16)	4		
14	19	825953	PLUG, (M14 x 12)	1		6
15	27	81990M	GASKET	1		6
16		11761002	ANODE	2		
17	10	95209001	SCREW	2		
18		11761001	ANODE	2		
19	10	827443001	SCREW	2		
20	17	82154M	PIN	2		
-	900	887844T 1	CYLINDER HEAD ASSEMBLY	1	(Starboard) SN# 1B055687 & Below	
-	900	887844T05	CYLINDER HEAD ASSEMBLY	1	(Starboard) SN# 1B055688 THRU	
-	900	887844T06	CYLINDER HEAD ASSEMBLY	1	(Starboard) SN# 1B227000 & Up	
-	900	887845T 1	CYLINDER HEAD ASSEMBLY	1	(Port) SN# 1B055687 & Below	
-	900	887845T05	CYLINDER HEAD ASSEMBLY	1	(Port) SN# 1B055688 THRU 1B22	
-	900	887845T06	CYLINDER HEAD ASSEMBLY	1	(Port) SN# 1B227000 & Up	
-	27	887810A03	GASKET SET, Powerhead	1	SN# 0T807875 & Below	
-	27	887810A04	GASKET SET, Powerhead	1	SN# 0T807876 THRU 1B055687	
-	27	887810A05	GASKET SET, Powerhead	1	SN# 1B055688 & Up	