



1436

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	1623	888680T 4	GEAR HOUSING ASSEMBLY, Con	1	[X-Long] SN# 1B226999 & Below	
-	1623	888680T08	GEAR HOUSING ASSEMBLY, Con	1	[X-Long] SN# 1B227000 & Up	
-	1623	888680T 5	GEAR HOUSING ASSEMBLY, Con	1	[XX-Long] SN# 1B226999 & Below	
-	1623	888680T09	GEAR HOUSING ASSEMBLY, Con	1	[XX-Long] SN# 1B227000 & Up	
1	1623	888680T 1	GEAR HOUSING (Basic)	1		
2		888700 1	SHIFTER	1		
3	15	888713A 1	SHIM SET	AR		
4	23	888716	SPACER	1		
5	31	888681 6	BEARING	1		
6	31	888681 7	BEARING	1		
7	43	888707T 1	GEAR, Reverse	1	SN# 1B226999 & Below	
7	43	888707T03	GEAR, Reverse	1	SN# 1B227000 & Up	
8	31	888681 8	BEARING	2		
9		888701	SHIFT SLIDE	1		
10		82346M	BALL	2		
11	11	881314 2	NUT	2		
12		888704	SHAFT	1		
13		888705	PLUNGER	2		
14	24	888703 1	SPRING	1		
15	12	804305 1	WASHER	1		
16	52	888702	CLUTCH	1		
17	17	888633 1	PIN	1		
18	24	888703	SPRING	1		
19	43	888698T 1	GEAR, Forward	1	SN# 1B226999 & Below	
19	43	888698T03	GEAR, Forward	1	SN# 1B227000 & Up	
20	11	889309	NUT	1		
21	14	888717	TAB WASHER	1		
22	15	888767A 1	SHIM SET	AR		
23	31	888681 9	BEARING	1		
24	44	888699 1	PROPELLER SHAFT	1		
25	31	888681 10	BEARING	1		
26	15	888766A 1	SHIM SET	1		
27	31	888681 5	BEARING	1		
28	25	881437 3	O-RING	2		15
29		888706T 1	BEARING CARRIER	1		
30	22	888374 1	FITTING, Grease	1		
31	10	881311 1	BOLT	2		
32	12	804305 3	WASHER	2		
33	26	888694 1	OIL SEAL	2		15
34		888708	CAP	1		
35	10	881311 2	BOLT (4.8 x 20)	2		