



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	482	887829T	CRANKSHAFT	1		5
2	26	887830	OIL SEAL	1		2,5
3	31	887833T	BEARING	4	(#1)	5
3	31	887833T10	BEARING	4	(#2)	5
3	31	887833T20	BEARING	4	(#3)	5
4	31	887834T	BEARING	3	(#1)	5
4	31	887834T10	BEARING	3	(#2)	5
4	31	887834T20	BEARING	3	(#3)	5
5	31	887835T	BEARING	1	(#1)	5
5	31	887835T10	BEARING	1	(#2)	5
5	31	887835T20	BEARING	1	(#3)	5
6	31	887836T	BEARING	2		5
7	647	887837A 1	CONNECTING ROD	6		5
8	10	887838	BOLT	12		5
9	31	887839T	BEARING	12	(Yellow)	5
9	31	887839T10	BEARING	12	(Green)	5
9	31	887839T20	BEARING	12	(Blue)	5
10	2720	887840A 1	PISTON	6	(Standard) SN# 1B055870 & Below	5
10	2720	887840A02	PISTON ASSEMBLY	6	(Standard) SN# 1B055871 & Up	5
10	2720	887840A03	PISTON ASSEMBLY	6	(Oversize)	
11	39	887841T	RING SET, PISTON	6	(Standard)	5
11	39	887841A02	RING SET, Piston	6	(Oversize)	
12		NSS	NOT SOLD SEPARATE, Piston F	6		5
13	53	887843	CLIP	12		5
14	28	826100 1	KEY	1		
15	28	804153	KEY	1		5
-		885225T03	POWERHEAD	1	SN# 1B055687 & Below	
-		885225T05	POWERHEAD	1	SN# 1B055688 THRU 1B226999	
-		885225T06	POWERHEAD	1	SN# 1B227000 & Up	
-	27	887810A03	GASKET SET, Powerhead	1	SN# 0T807875 & Below	
-	27	887810A04	GASKET SET, Powerhead	1	SN# 0T807876 THRU 1B055687	
-	27	887810A05	GASKET SET, Powerhead	1	SN# 1B055688 & Up	