



1433

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1623	888680T 2	GEAR HOUSING ASSEMBLY, Con	1	[X-Long](Standard) SN# 1B22699	
-	1623	888680T06	GEAR HOUSING ASSEMBLY, Con	1	[X-Long](Standard) SN# 1B22700	
-	1623	888680T 3	GEAR HOUSING ASSEMBLY, Con	1	[XX-Long](Standard) SN# 1B2269	
-	1623	888680T07	GEAR HOUSING ASSEMBLY, Con	1	[XX-Long](Standard) SN# 1B2270	
-	1623	888680T 4	GEAR HOUSING ASSEMBLY, Con	1	[X-Long](Counter Rotation) SN# 11	
-	1623	888680T08	GEAR HOUSING ASSEMBLY, Con	1	[X-Long](Counter Rotation) SN# 11	
-	1623	888680T 5	GEAR HOUSING ASSEMBLY, Con	1	[XX-Long](Counter Rotation) SN#	
-	1623	888680T09	GEAR HOUSING ASSEMBLY, Con	1	[XX-Long](Counter Rotation) SN#	
1	1623	888680T 1	GEAR HOUSING (Basic)	1		
2	31	888681	BEARING	1		
3	43	888697	PINION GEAR	1	SN# 1B226999 & Below	
3	43	888697T01	GEAR, Pinion	1	SN# 1B227000 & Up	
4	12	888380 12	WASHER	1		
5	11	881314 1	NUT	1		
6	22	95632M	DRAIN PLUG	1		
7	27	81987	GASKET	2		15
8	26	81426M	WATER SEAL	1		
9	22	81924M	PLUG	1		
10		888682	GUIDE	1		
11		888685 3	DAMPER	1		
12	45	888696	DRIVESHAFT	1	[X-Long]	
12	45	888696 1	DRIVESHAFT	1	[XX-Long]	
13	28	881342 1	KEY	1		18
14	31	888681 3	BEARING	1		
15	15	888715A 1	SHIM SET	AR		
16	31	888681 2	BEARING	1		
17	25	881437 2	O-RING	1		15
18		888693	HOUSING	1		
19	10	887827 2	BOLT	4		
20	11	852816 5	NUT	1		
21	26	888694	OIL SEAL	2		15
22		888695	COVER	1		
23	27	888692	GASKET	1		15,18
24		888691	OUTER PLATE	1		18
25	47	888689	IMPELLER	1		18
26		888687	INSERT	1		18
27	12	855682 2	WASHER	2		
28	13	888363 2	WAVE WASHER	1		
29	23	888690	SPACER	1		
30	23	888690 1	COLLAR	1		
31	25	825579 2	O-RING	1		15,18